



Operator's Manual

Serial Number Range

GR-12
GR-15
GR-20

from GR10-20000

ANSI/CSA
North America
South America
Asia

with
Maintenance
Information

Fifth Edition
First Printing
Part No. 133571

Important

Read, understand and obey these safety rules and operating instructions before operating this machine. Only trained and authorized personnel shall be permitted to operate this machine. This manual should be considered a permanent part of your machine and should remain with the machine at all times. If you have any questions, call Genie Industries.

Contents

	Page
Introduction	1
Symbol and Hazard Pictorials Definitions	3
General Safety	5
Personal Safety	9
Work Area Safety	10
Legend	18
Controls	19
Inspections	22
Operating Instructions	35
Transport and Lifting Instructions	40
Maintenance	43
Specifications	45

Contact us:


Internet: <http://www.genielift.com>
 e-mail: techpub@genieind.com

Copyright © 2000 by Genie Industries

Fifth Edition: First Printing, May 2010

"Genie" is a registered trademark of Genie Industries in the U.S.A. and many other countries. "Runabout" and "GR" are trademarks of Genie Industries.

These machines comply with
 ANSI/SIA 92.6
 CSA B.354.2

 Printed on recycled paper

Introduction

Owners, Users and Operators:

Genie appreciates your choice of our machine for your application. Our number one priority is user safety, which is best achieved by our joint efforts. We feel that you make a major contribution to safety if you, as the equipment users and operators:

- 1 **Comply** with employer, job site and governmental rules.
- 2 **Read, understand and follow** the instructions in this and other manuals supplied with this machine.
- 3 **Use good safe work practices** in a commonsense way.
- 4 **Only have trained/certified operators**, directed by informed and knowledgeable supervision, running the machine.

If there is anything in this manual that is not clear or which you believe should be added, please contact us.

Internet: www.genielift.com

E-mail: techpub@genieind.com



Danger

Failure to obey the instructions and safety rules in this manual will result in death or serious injury.

Do Not Operate Unless:

- You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

Know and understand the safety rules before going on to the next section.

- 2 Always perform a pre-operation inspection.
- 3 Always perform function tests prior to use.
- 4 Inspect the workplace.
- 5 Only use the machine as it was intended.

- You read, understand and obey the manufacturer's instructions and safety rules—safety and operator's manuals and machine decals.
- You read, understand and obey employer's safety rules and work site regulations.
- You read, understand and obey all applicable governmental regulations.
- You are properly trained to safely operate the machine.

Introduction

Hazard Classification

Genie uses symbols, color coding and signal words to identify the following:



Safety alert symbol—used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

▲ DANGER

Red

Indicates a hazardous situation which, if not avoided, will result in death or serious injury.

▲ WARNING

Orange

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

▲ CAUTION

Yellow

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Blue

Indicates a hazardous situation which, if not avoided, could result in property damage.


























Intended Use

This machine is intended to be used only to lift personnel, along with their tools and materials to an aerial work site.












Safety Sign Maintenance

Replace any missing or damaged safety signs. Keep operator safety in mind at all times. Use mild soap and water to clean safety signs. Do not use solvent-based cleaners because they may damage the safety sign material.

Symbol and Hazard Pictorials Definitions

 Read the operator's manual	 Read the service manual	 Crush hazard	 No smoking	 Collision hazard
 Collision hazard	 Tip-over hazard	 Tip-over hazard	 Use a piece of cardboard or paper to search for leaks	 Electrocution hazard
 Electrocution hazard	 Explosion hazard	 Fire hazard	 Burn hazard	 Skin injection hazard
 Transport diagram	 Tiedown	 Keep away from moving parts	 Move machine to level ground	 Batteries used as counterweights
 Maintain required clearance	 Only trained maintenance personnel should access compartments	 Chock the wheels	 Release brakes	 Grounded AC 3-wire only

Symbol and Hazard Pictorials Definitions

 <p>Replace damaged wires and cords</p>	 <p>Wheel load</p>	 <p>Side force</p>	 <p>Lanyard attachment point</p>	 <p>Voltage rating for power to platform</p>
 <p>Pressure rating for air line to platform</p>	 <p>Wind speed</p>			
  <p>Maximum capacity including occupant</p>		  <p>Maximum capacity including occupant, tools and tray</p> <p>22 kg</p>		

General Safety

Safety signs and locations Decals with words

133014

⚠ DANGER

Failure to read, understand and obey the operator's manual and the following safety rules will result in death or serious injury.

Improper Use Hazard
The operator is responsible for safe machine operation. This includes:

- 1 Avoid hazardous situations.
- 2 Always perform a pre-operation inspection.
- 3 Always perform function tests prior to use.
- 4 Inspect the work place.
- 5 Only use the machine as it was intended.

Do not operate unless:

You read, understand and obey:

- manufacturer's instructions and safety rules—
- safety and operator's manuals and decals
- employer's safety rules
- applicable governmental regulations

You are properly trained to safely operate this machine.

Electrocution Hazards

This machine is not electrically insulated and will not provide protection from contact with or proximity to electrical current.

Maintain safe distances from electrical power lines and apparatus in accordance with applicable governmental regulations and the following chart.

Line voltage	Required clearance
0 to 50kV	10 ft 3.05 m
50kV to 200kV	15 ft 4.60 m
200kV to 350kV	20 ft 6.10 m
350kV to 500kV	25 ft 7.62 m
500kV to 750kV	35 ft 10.67 m
750kV to 1000kV	40 ft 12.20 m

Explosion Hazards

Do not operate machine or charge battery in hazardous locations or locations where potentially flammable or explosive gases or particles may be present.

Tip-over Hazards

Do not exceed rated load capacity. Maximum occupancy: 1 person.

Do not raise platform when wind speeds may exceed 28 mph / 12.5 m/s.

Do not operate machine in strong or gusty winds. Do not increase surface area of platform or load. Increasing area exposed to wind will decrease machine stability.

Do not drive machine on or near uneven terrain, unstable surfaces or other hazardous conditions with the platform raised.

Use extreme care and slow speeds while driving the machine in stowed position across uneven terrain, debris, unstable or slippery surfaces and near holes and drop-offs.

Do not place or attach overhanging loads to any part of this machine.

Do not push off or pull toward any object outside of the platform.

Do not alter or disable machine components that in any way affect safety and stability.

Do not place ladders or scaffolds in platform or against any part of this machine.

Do not drive machine on a slope that exceeds the maximum slope or slide slope rating of the machine.

Do not use machine on a moving or mobile surface or vehicle.

Be sure all tires are in good condition, castle nuts are properly tightened and cotter pins are properly installed.

Do not depend on tilt alarm as a level indicator. Tilt alarm sounds only when the machine is on a slope.

If tilt alarm sounds, lower the platform. Move machine to a firm, level surface. Use extreme caution to lower platform.

Do not alter or disable limit switches.

Crushing Hazards

Use common sense and planning when operating machine with controller from ground. Maintain safe distances between operator, machine and fixed objects.

Fall Hazards

The guard rail system provides fall protection. If occupants of the platform are required to wear personal fall protection equipment (PPPE) due to job site or employer rules, PPPE equipment and its use shall be in accordance with the PPPE manufacturer's instructions and applicable governmental requirements.

Do not sit, stand or climb on the platform guard rails. Maintain a firm footing on the platform floor at all times.

Do not climb down from the platform when raised.

Lower platform mid-rail bar or close platform gate before operating.

Keep platform floor clear of debris.

Collision Hazards

Be aware of limited sight distance and blind spots when driving or operating.

Check work area for overhead obstructions or other possible hazards.

Be aware of crushing hazard when grasping platform guard rail.

Do not lower platform unless area below is clear of personnel and obstructions.

Be aware of extended platform position when moving machine.

No sturt driving or horseplay while operating a machine.

Damaged Machine Hazards

Do not use a damaged or malfunctioning machine.

Be sure all maintenance has been performed as specified in the appropriate operator's and service manuals.

Be sure all decals are in place and legible.

Be sure operator's, safety and responsibilities manuals are complete, legible and in the storage container located on the platform.

44736

⚠ DANGER

Tip-over Hazard
If tilt-alarm sounds, unit is on a severe slope. Death or serious injury could occur.

1 Lower the platform.

2 Move the machine to level surface.

31508

⚠ DANGER

Electrocution / Fire Hazard
Death or serious injury will result from use of improper or damaged cord and outlet.

Connect charger to a grounded AC 3-wire electrical outlet only.

Before each use, inspect for damaged cord, cables and wires. Replace damaged items before operating.


Part No. 133571

GR-12 • GR-15 • GR-20

5


General Safety

Safety signs and locations Decals with words



General Safety

Safety signs and locations Decals with symbols



Personal Safety

Fall Protection

Personal fall protection equipment (PFPE) is not required when operating this machine. If PFPE is required by job site or employer rules, the following shall apply:

All PFPE must comply with applicable governmental regulations, and must be inspected and used in accordance with the PFPE manufacturer's instructions.

Work Area Safety

⚠️ Electrocutation Hazards



This machine is not electrically insulated and will not provide protection from contact with or proximity to electrical current.



Maintain safe distances from electrical power lines and apparatus in accordance with applicable governmental regulations and the following chart.

Line Voltage	Required Clearance	
0 to 50KV	10 ft	3.05 m
50KV to 200KV	15 ft	4.60 m
200KV to 350KV	20 ft	6.10 m
350KV to 500KV	25 ft	7.62 m
500KV to 750KV	35 ft	10.67 m
750KV to 1000KV	45 ft	13.72 m

Allow for platform movement, electrical line sway or sag and beware of strong or gusty winds.

Keep away from the machine if it contacts energized power lines. Personnel on the ground or in the platform must not touch or operate the machine until energized power lines are shut off.

Do not operate the machine during lightning or storms.

Do not use the machine as a ground for welding.

⚠️ Tip-over Hazards

Occupants, equipment and materials must not exceed the maximum platform capacity or the maximum capacity of the platform extension. Weight in trays are part of the total platform load.

Maximum capacity - GR-12 and GR-15

Standard platform

Platform without extension	500 lbs	227 kg
Platform retracted	500 lbs	227 kg
Platform extended - Platform only	250 lbs	113 kg
Platform extended - Extension only	250 lbs	113 kg
Work station tray (option)	50 lbs	22 kg
Maximum occupants		1

500 lbs / 227 kg Extension only Platform only
250 lbs / 113 kg 250 lbs / 113 kg




AWP platform	350 lbs	159 kg
Maximum occupants		1

Work Safety

Maximum capacity - GR-20		
Standard platform		
Platform without extension	350 lbs	159 kg
Platform retracted	350 lbs	159 kg
Platform extended - Platform only	100 lbs	45 kg
Platform extended - Extension only	250 lbs	113 kg
Maximum occupants	1	

350 lbs / 159 kg	Extension only 250 lbs / 113 kg	Platform only 100 lbs / 45 kg
------------------	------------------------------------	----------------------------------



AWP platform	350 lbs	159 kg
Maximum occupants	1	



Do not raise the platform unless the machine is on a firm, level surface.



Do not depend on the tilt alarm as a level indicator. The tilt alarm sounds at the platform controls and ground controls when the machine is on a severe slope.

If the tilt alarm sounds:

Lower the platform. Move the machine to a firm, level surface. If the tilt alarm sounds when the platform is raised, use extreme caution to lower the platform.

Do not drive over 0.5 mph / 0.8 km/h with the platform raised.

Work Area Safety

Do not raise the mast when wind speeds may exceed 28 mph / 12.5 m/s. If wind speeds exceed 28 mph / 12.5 m/s when the platform is raised, lower the platform and do not continue to operate the machine.



Do not operate the machine in strong or gusty winds. Do not increase the surface area of the platform or the load. Increasing the area exposed to the wind will decrease machine stability.



Use extreme care and slow speeds while driving the machine in a stowed position across uneven terrain, debris, unstable or slippery surfaces and near holes and drop-offs.

Do not drive the machine on or near uneven terrain, unstable surfaces or other hazardous conditions with the platform raised.

Do not use the machine as a crane.

Do not push the machine or other objects with the platform.

Do not contact adjacent structures with the platform.

Do not tie the platform to adjacent structures.

Do not place loads outside the platform perimeter. Work station tray is considered part of the platform.

Do not use the platform controls to free a platform that is caught, snagged or otherwise prevented from normal motion by an adjacent structure. All personnel must be removed from the platform before attempting to free the platform using the ground controls.



Do not push off or pull toward any object outside of the platform.

Model	Maximum allowable side force	Maximum number of occupants
ANSI/CSA	100 lbs / 445 N	1

Do not alter or disable the limit switches.

Do not alter or disable machine components that in any way affect safety and stability.

Do not replace items critical to machine stability with items of different weight or specification.

Do not use batteries that weigh less than the original equipment. Batteries are used as counterweight and are critical to machine stability. Each battery must weigh 62 pounds / 28 kg.

Do not modify or alter an aerial work platform without prior written permission from the manufacturer. Mounting attachments for holding tools or other materials onto the platform, toeboards or guard rail system can increase the weight in the platform and the surface area of the platform or the load.

Work Area Safety



Do not place or attach fixed or overhanging loads to any part of this machine.

Do not place ladders or scaffolds in the platform or against any part of this machine



Do not transport tools and materials unless they are evenly distributed and can be safely handled by the person in the platform.

Do not use the machine on a moving or mobile surface or vehicle.



Be sure all tires are in good condition, castle nuts are properly tightened and cotter pins are properly installed.

⚠️ Crushing Hazard

Keep hands and limbs out of mast.

Do not work under the platform or mast without the battery cover raised.

Use common sense and planning when operating the machine with the controller from the ground. Maintain safe distances between the operator, the machine and fixed objects.

⚠️ Operation on Slopes Hazards

Do not drive the machine on a slope that exceeds the slope and side slope rating of the machine. Slope rating applies to machines in the stowed position only.

Maximum slope rating, stowed position	30% (17°)
--	-----------

Maximum side slope rating, stowed position	30% (17°)
---	-----------

Note: Slope rating is subject to ground conditions and adequate traction.

Work Area Safety

⚠ Fall Hazards

The guard rail system provides fall protection. If the occupant of the platform is required to wear personal fall protection equipment (PFPE) due to job site or employer rules, PFPE and its use shall be in accordance with the PFPE manufacturer's instructions and applicable governmental requirements. Use approved lanyard attachment point provided.

Keep the platform floor clear of debris.

Lower the platform mid-rail bar or close the entry gate before operating.



Do not sit, stand or climb on the platform guard rails. Maintain a firm footing on the platform floor at all times.



Do not climb down from the platform when raised.
Do not enter or exit the platform unless the machine is in the stowed position.

Lower the platform mid-rail bar or close the platform entry gate before operating.

⚠ Collision Hazards



Be aware of limited sight distance and blind spots when driving or operating.

Be aware of the extended platform position when moving the machine.

The machine must be on a level surface or secured before releasing the brakes.



Check the work area for overhead obstructions or other possible hazards.



Be aware of crushing hazards when grasping the platform guard rail.

Work Area Safety

Operators must comply with employer, job site and governmental rules regarding use of personal protective equipment.



Do not lower the platform unless the area below is clear of personnel and obstructions.



Limit travel speed according to the condition of the ground surface, congestion, slope, location of personnel, and any other factors which may cause collision.

Do not operate a machine in the path of any crane or moving overhead machinery unless the controls of the crane have been locked out and/or precautions have been taken to prevent any potential collision.

No stunt driving or horseplay while operating a machine.

Work Area Safety

⚠ Bodily Injury Hazard

Do not operate the machine with a hydraulic oil or air leak. An air leak or hydraulic leak can penetrate and/or burn skin.

Improper contact with components under any cover will cause serious injury. Only trained maintenance personnel should access compartments. Access by the operator is only advised when performing a pre-operation inspection. All compartments must remain closed and secured during operation.

⚠ Explosion and Fire Hazards

Do not operate the machine or charge the battery in hazardous locations or locations where potentially flammable or explosive gases or particles may be present.

⚠ Damaged Machine Hazards

Do not use a damaged or malfunctioning machine.

Conduct a thorough pre-operation inspection of the machine and test all functions before each work shift. Immediately tag and remove from service a damaged or malfunctioning machine.

Be sure all maintenance has been performed as specified in this manual and the appropriate service manual.

Be sure all decals are in place and legible.

Be sure the operator's, safety, and responsibilities manuals are complete, legible and in the storage container located on the platform.

⚠ Component Damage Hazards

Do not use any battery charger greater than 24V to charge the batteries.

Do not use the machine as a ground for welding.

Work Area Safety

⚠ Battery Safety

Burn Hazards



Batteries contain acid. Always wear protective clothing and eye wear when working with batteries.

Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

Do not expose the batteries or the charger to water or rain during charging.

Explosion Hazards



Keep sparks, flames and lighted tobacco away from batteries. Batteries emit an explosive gas.



The battery tray should remain open during the entire charging cycle.



Do not contact the battery terminals or the cable clamps with tools that may cause sparks.

Component Damage Hazard

Do not use any battery charger greater than 24V to charge the batteries.

Electrocution/Burn Hazards



Connect the battery charger to a grounded, AC 3-wire electrical outlet only.

Inspect daily for damaged cords, cables and wires. Replace damaged items before operating.

Avoid electrical shock/burns from contact with battery terminals. Remove all rings, watches and other jewelry.

Tip-over Hazard

Do not use batteries that weigh less than the original equipment. Batteries are used as counterweight and are critical to machine stability. Each battery must weigh 62 pounds / 28 kg.


Lifting Hazard

Use the appropriate number of people and proper lifting techniques when lifting batteries.

Lockout After Each Use


- 1 Select a safe parking location—firm level surface, clear of obstruction and traffic.
- 2 Lower the platform.
- 3 Turn the key switch to the off position and remove the key to secure from unauthorized use.
- 4 Chock the wheels.
- 5 Charge the batteries.

Legend



- | | | |
|---------------------------------|---|-------------------------------------|
| 1 Pothole guard | 10 Power to platform/battery charger connection for optional inverter | 17 GFCI outlet |
| 2 Non-steer tire | 11 Work station tray (if equipped) | 18 Manual storage container |
| 3 Emergency lowering valve | 12 Brake release pump knob (under covers) | 19 Battery compartment cover |
| 4 Transport tie-down | 13 Mid-rail entry bar | 20 Battery cover latch |
| 5 Forklift pocket | 14 Platform controls | 21 Steer tire |
| 6 Battery charger display | 15 Lanyard anchorage point | 22 Platform extension release pedal |
| 7 Covers | 16 Mast | 23 Platform extension entry gate |
| 8 Ground controls | | |
| 9 Hydraulic oil level indicator | | |

Controls



Ground Control Panel

1 7 amp breaker for electric circuits

2 Red Emergency Stop button

Push in the red Emergency Stop button to the off position to stop all functions. Pull out the red Emergency Stop button to the on position to operate the machine.

3 Menu down button

4 Menu enter button

5 Platform up button

6 Platform down button

7 Lift function enable button

Press and hold this button to activate the lift function.

8 Menu escape button

9 Menu up button


10 LCD diagnostic readout

11 Key switch for platform/off/ground selection

Turn the key switch to the platform position and the platform controls will operate. Turn the key switch to the off position and the machine will be off. Turn the key switch to the ground position and the ground controls will operate.



Controls



Platform Control Panel

- | | |
|---|---|
| 1 Thumb rocker switch for steer functions | 6 Red Emergency Stop button |
| 2 LED diagnostic readout/battery charge indicator | 7 Low speed lift enable button |
| 3 Platform up button | 8 High speed lift enable button |
| 4 Numeric keypad (if equipped) | 9 Drive speed select button |
| 5 Platform down button | 10 Horn button |
| | 11 Proportional control handle and function enable switch for drive and steer functions |

Controls

Platform Control Panel

- 1 Thumb rocker switch for steer function

Press the left side of the thumb rocker and the machine will turn in the direction the blue triangle points on the platform control panel.



Press the right side of the thumb rocker and the machine will turn in the direction the yellow triangle points on the platform control panel.



- 2 LED diagnostic read out, battery charge indicator.

- 3 Platform up button

Press and hold the platform up button and the platform will raise.



- 4 Numeric key pad (if equipped)

- 5 Platform down button

Press and hold the platform down button and the platform will lower.



- 6 Red Emergency Stop button

Push in the red Emergency Stop button to the off position to stop all functions. Pull out the red Emergency Stop button to the on position to operate the machine.

- 7 Low speed lift enable button

Press and hold this button to activate the low speed platform function.



- 8 High speed lift enable button

Press and hold this button to activate the high speed platform function.



- 9 Drive speed button

Press this button to activate the slow drive function. The indicator light will be on when slow drive is selected.



- 10 Horn Button

Press the horn button and the horn will sound. Release the horn button and the horn will not sound.



- 11 Proportional control handle and function enable switch for drive/steer function

Press and hold the function enable switch on the platform control handle to activate the drive or steer function.

Move the control handle in the direction indicated by the blue arrow on the platform control panel and the machine will move in the direction the blue arrow points. Move the control handle in the direction indicated by the yellow arrow on the platform control panel and the machine will move in the direction the yellow arrow points.

Inspections



Do Not Operate Unless:

- You learn and practice the principles of safe machine operation contained in this operator's manual.

1 Avoid hazardous situations.

2 Always perform a pre-operation inspection.

Know and understand the pre-operation inspection before going on to the next section.

3 Always perform function tests prior to use.

4 Inspect the workplace.

5 Only use the machine as it was intended.

Pre-operation Inspection Fundamentals

It is the responsibility of the operator to perform a pre-operation inspection and routine maintenance.

The pre-operation inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests.

The pre-operation inspection also serves to determine if routine maintenance procedures are required. Only routine maintenance items specified in this manual may be performed by the operator.

Refer to the list on the next page and check each of the items.

If damage or any unauthorized variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications. After repairs are completed, the operator must perform a pre-operation inspection again before going on to the function tests.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

Inspections

Pre-operation Inspection

- Be sure that the operator's, safety and responsibilities manuals are complete, legible and in the storage container located on the platform.
- Be sure that all decals are legible and in place. See Inspections section.
- Check for hydraulic oil leaks and proper oil level. Add oil if needed. See Maintenance section.
- Check for battery fluid leaks and proper fluid level. Add distilled water if needed. See Maintenance section.

Check the following components or areas for damage, improperly installed or missing parts and unauthorized modifications:

- Electrical components, wiring and electrical cables
- Hydraulic power unit, tank, hoses, fittings, cylinders and manifolds
- Battery pack and connections
- Drive motors
- Tires and wheels
- Ground strap
- Limit switches, alarms and horn
- Alarms and beacons (if equipped)
- Nuts, bolts and other fasteners
- Platform entry mid-rail bar, chain or gate
- Sequencing cables and pulleys
- Pothole guards
- Platform extension (if equipped)
- Work tray (if equipped)

- Brake release components
- Battery cover
- Mast columns and counterweight
- Platform control joystick

Check the entire machine for:

- Cracks in welds or structural components
- Dents or damage to the machine
- Excessive rust, corrosion or oxidation
- Be sure that all structural and other critical components are present and all associated fasteners and pins are in place and properly tightened.

Note: If the platform must be raised to inspect the machine, make sure the battery cover is in place. See Operating Instructions section.

Inspections



Do Not Operate Unless:

- You learn and practice the principles of safe machine operation contained in this operator's manual.

- 1 Avoid hazardous situations.
- 2 Always perform a pre-operation inspection.

3 Always perform function tests prior to use.

Know and understand the function tests before going on to the next section.

- 4 Inspect the workplace.
- 5 Only use the machine as it was intended.

Function Test Fundamentals

The function tests are designed to discover any malfunctions before the machine is put into service. The operator must follow the step-by-step instructions to test all machine functions.

A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service. Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications.

After repairs are completed, the operator must perform a pre-operation inspection and function tests again before putting the machine into service.

Inspections


- 1 Select a test area that is firm, level and free of obstruction.
- 2 Be sure the batteries are connected.

At the Ground Controls

- 3 Pull out the platform and ground red Emergency Stop buttons to the on position.
 - 4 Turn the key switch to ground control.
 - 5 Observe the LED diagnostic readout on the platform controls.
- ⦿ Result: The LED readout should look like the picture below.



- 6 Observe the LCD diagnostic readout on the ground controls.
- ⦿ Result: The LCD readout should display READY, the machine model and machine hours. Refer to the example below.



Test Emergency Stop

- 7 Push in the ground red Emergency Stop button to the off position.
- ⦿ Result: No functions should operate.
- 8 Pull out the red Emergency Stop button to the on position.

Test the Up/Down Functions

The audible warnings on this machine and the standard horn all come from the same central alarm. The horn is a constant tone. The descent alarm sounds at 60 beeps per minute. The alarm sounds at 180 beeps per minute when the pothole guards have not deployed and when the machine is not level. An optional automotive-style horn is also available.

- 9 Do not press the lift function enable button.
 - 10 Press the platform up or platform down button.
- ⦿ Result: The lift function should not operate.
- 11 Do not press the platform up or platform down buttons.
 - 12 Press the lift function enable button.
- ⦿ Result: The lift function should not operate.
- 13 Press and hold the lift function enable button, and press the platform up button.
- ⦿ Result: The platform should raise.
- 14 Press and hold the lift function enable button, and press the platform down button.
- ⦿ Result: The platform should lower. The descent alarm should sound while the platform is lowering.

Test Emergency Lowering

- 15 Activate the up function by pressing the lift enable button and platform up button, and raise the platform approximately 2 ft / 60 cm.
 - 16 Pull the Emergency lowering knob located at the base of the machine below the mast.
- ⦿ Result: The platform should lower. The descent alarm will not sound.
- 17 Turn the key switch to platform control.

Inspections

At the Platform Controls

Test Emergency Stop

18 Push in the platform red Emergency Stop button to the off position.

- ☉ Result: No functions should operate.

Test the Horn

19 Pull out the red Emergency Stop button to the on position.

20 Push the horn button.

- ☉ Result: The horn should sound.

Test the Drive/Steer Function Enable Switch

21 Do not hold the drive/steer function enable switch on the control handle.

22 Slowly move the control handle in the direction indicated by the blue arrow, then in the direction indicated by the yellow arrow.

- ☉ Result: No functions should operate.

Test the Lift Enable Buttons

23 Do not press the high speed or low speed lift enable buttons.

24 Press the platform up or platform down button.

- ☉ Result: The lift function should not operate.

25 Do not press the platform up or platform down buttons.

26 Press the high speed or low speed lift enable button.

- ☉ Result: The lift function should not operate.

Test the Up/Down Functions

27 Press and hold the high speed lift enable button.

28 Press the platform up button.

- ☉ Result: The platform should raise. The pothole guards should deploy.

29 Release the high speed lift enable button or the platform up button.

- ☉ Result: The platform should stop raising.

30 Press and hold the high speed lift enable button.

31 Press the platform down button.

- ☉ Result: The platform should lower. The descent alarm should sound while the platform is lowering.

32 Release the high speed lift enable button or the platform down button.

- ☉ Result: The platform should stop lowering.

33 Press and hold the low speed lift enable button.

34 Press the platform up button.

- ☉ Result: The platform should raise. The pothole guards should deploy.

35 Release the low speed lift enable button or the platform up button.

- ☉ Result: The platform should stop raising.

36 Press and hold the low speed lift enable button.

37 Press the platform down button.

- ☉ Result: The platform should lower at the same descent speed as high speed. The descent alarm should sound while the platform is lowering.

38 Release the low speed lift enable button or the platform down button.

- ☉ Result: The platform should stop lowering.

Inspections

Test the Steering

Note: When performing the steer and drive function tests, stand in the platform facing the steer end of the machine.


- 39 Press and hold the drive/steer function enable switch on the control handle.
- 40 Press the thumb rocker switch on top of the control handle in the direction indicated by the blue triangle on the control panel.
 - ⦿ Result: The steer wheels should turn in the direction that the blue triangle points on the control panel.
- 41 Press the thumb rocker switch in the direction indicated by the yellow triangle on the control panel.
 - ⦿ Result: The steer wheels should turn in the direction that the yellow triangle points on the control panel.

Test Drive and Braking

- 42 Press and hold the drive/steer function enable switch on the control handle.
- 43 Slowly move the control handle in the direction indicated by the blue arrow on the control panel until the machine begins to move, then return the handle to the center position.
 - ⦿ Result: The machine should move in the direction the blue arrow points on the control panel, then come to an abrupt stop when the control handle is returned to the center position.
- 44 Slowly move the control handle in the direction indicated by the yellow arrow on the control panel until the machine begins to move, then return the handle to the center position.
 - ⦿ Result: The machine should move in the direction the yellow arrow points on the control panel, then come to an abrupt stop when the control handle is returned to the center position.

Note: The brakes must be able to hold the machine on any slope it is able to climb.

Test the Tilt Sensor Operation

- 45 Open the ground controls cover and locate the tilt sensor behind the ground controls panel.
- 46 Press down one side of the tilt sensor and place the tilt sensor test tool under one of the posts.
 
- 47 Test all ground and platform control functions.
 - ⦿ Result: Before the platform is raised approximately 1 ft / 30 cm, the lift function should stop. The alarm at the platform controls and ground controls should sound.
 - ⦿ Result: The drive function should not work either direction.
 - ⦿ Result: The platform controls LED diagnostic readout should display LL and the ground controls LCD diagnostic readout should display LL: Machine Tilted.
- 48 Remove the tilt sensor test tool.
- 49 Turn the key switch to platform control.

Inspections

Test Elevated Drive Speed

50 Press and hold the high or low speed lift enable button.

51 Press the platform up button and raise the platform approximately 2 ft / 60 cm from the ground.

52 Press and hold the drive/steer function enable switch on the control handle. Slowly move the control handle to the full drive position.

- ⦿ Result: The maximum achievable drive speed with the platform raised should not exceed 0.72 ft / 0.22 m per second.

If the drive speed with the platform raised exceeds 0.72 ft / 0.22 m per second, immediately tag and remove the machine from service.

Test the Pothole Guards

Note: The pothole guards should automatically deploy when the platform is raised. The pothole guards activate limit switches that allow the machine to continue to function. If the pothole guards do not deploy, an alarm sounds and the machine will not drive or steer.

53 Press and hold the high or low speed lift enable button, and press the platform up button to raise the platform.

- ⦿ Result: When the platform is raised 4 ft / 1.2 m from the ground, the pothole guards should deploy.

54 Press on the pothole guards on one side, and then the other.

- ⦿ Result: The pothole guards should not move.

55 Press and hold the high or low speed lift enable button, and press the platform down button to lower the platform.

- ⦿ Result: The pothole guards should return to the stowed position.

56 Place a 2x4 or similar piece of wood under a pothole guard.

57 Press and hold the high or low speed lift enable button, and press the platform up button to raise the platform.

- ⦿ Result: Before the platform is raised 7 ft / 2.1 m from the ground an alarm should sound. The platform controls LED diagnostic readout should display PHS and the ground controls LCD diagnostic readout should display PHS: Pothole Guard Stuck.

58 Press and hold the drive/steer function enable switch on the control handle.

59 Slowly move the control handle in the direction indicated by the blue and yellow arrows on the control panel.

- ⦿ Result: The machine should not move forward or backward.

60 Press and hold the drive/steer function enable switch on the control handle.

61 Press the thumb rocker switch on top of the control handle in the direction indicated by the blue and yellow triangles on the control panel.

- ⦿ Result: The steer wheels should not turn left or right.

62 Press and hold the high or low speed lift enable button, and press the platform down button to lower the platform.

63 Remove the 2x4 or similar piece of wood.

Inspections



Do Not Operate Unless:

- You learn and practice the principles of safe machine operation contained in this operator's manual.

- 1 Avoid hazardous situations.
- 2 Always perform a pre-operation inspection.
- 3 Always perform function tests prior to use.

4 Inspect the workplace.

Know and understand the workplace inspection before going on to the next section.

- 5 Only use the machine as it was intended.

Fundamentals

The workplace inspection helps the operator determine if the workplace is suitable for safe machine operation. It should be performed by the operator prior to moving the machine to the workplace.

It is the operator's responsibility to read and remember the workplace hazards, then watch for and avoid them while moving, setting up and operating the machine.

Workplace Inspection

Be aware of and avoid the following hazardous situations:

- drop-offs or holes
- bumps, floor obstructions or debris
- sloped surfaces
- unstable or slippery surfaces
- overhead obstructions and high voltage conductors
- hazardous locations
- inadequate surface support to withstand all load forces imposed by the machine
- wind and weather conditions
- the presence of unauthorized personnel
- other possible unsafe conditions

Inspections


Inspection for Decals with Words Standard and AWP Platforms

Determine whether the decals on your machine have words or symbols. Use the appropriate inspection to verify that all decals are legible and in place.

Part No.	Description	Quantity
28174	Label - Power to Platform, 230V	2
28175	Warning - Compartment Access	1
28235	Label - Power to Platform, 115V	2
28236	Warning - Improper Operation	1
28373	Label - Forklift Pocket	2
31508	Danger - Electrocutation Hazard, Plugs	1
31788	Danger - Battery/Charger Safety	1
38122	Label - Manual Storage Container	1
38149	Label - Patents	1
40434	Label - Lanyard Anchorage	1
43658	Label - Power to Charger, 230V	1
44736	Danger - Tip-over Hazard, Tilt Alarm	1
44980	Label - Power to Charger, 115V	1
52475	Label - Transport Tie-down	3
52865	Warning - Annual Service Inspection	1
72086	Label - Lifting Eye	1
72155	Instructions - Max Capacity, 350 lbs / 159 kg (models with AWP platform)	1
72159	Danger - Tip-over Hazard, Batteries	1
72171	Instructions - Max Side Force, 100 lbs / 445 N, ANSI & CSA	1
72184	Cosmetic - Genie Runabout	2
72188	Label - Directional Arrows	2
72832	Danger - Do Not Alter Limit Switch	1
72850	Instructions - Work Tray Capacity 50 lbs / 22 kg, GR-12, GR-15	1
72970	Instructions - Battery Charger Operations	1
82366	Label - Chevron Rando	1
82975	Danger - Collision Hazard	1
97810	Cosmetic - Genie GR-12	2

Part No.	Description	Quantity
97811	Cosmetic - Genie GR-15	2
97812	Cosmetic - Genie GR-20	2
97815	Label - Lower Mid-rail	1
97828	Instructions - Max Capacity, 350 lbs / 159 kg, GR-20 (models with standard platform)	1
114325	Instructions - Battery Connection Diagram	1
133013	Danger - Electrocutation Hazard	1
133014	Danger - General Safety Rules	1
133092	Danger - Crushing Hazard, Use Safety Chock	1
133144	Label - Transport Diagram	2
133277	Label - Emergency Lowering	1
133585	Instructions - Operating Instructions, Platform	1
133586	Instructions - Operation, Ground Control	1
133596	Label - Operational Indicator Codes	1
137605	Label - Emergency Stop, Platform Control	1
137635	Label - Ground Control Panel	1
137636	Overlay - Platform Control Panel	1
137656	Label - Drive/Steer Direction, Platform Control	1
T106667	Label - Wheel Load, GR-12	4
T106668	Label - Wheel Load, GR-15	4
T106669	Label - Wheel Load, GR-20	4
T107029	Instructions - Brake Release Safety and Operation	1
T107894	Label - Tire Specifications	4
T108736	Instructions - Max Capacity, 500 lbs / 227 kg, GR-12, GR-15 (models with standard platform)	1

Inspections



Inspections


Inspection for Decals with Symbols Standard and AWP Platform




Determine whether the decals on your machine have words or symbols. Use the appropriate inspection to verify that all decals are legible and in place.

Part No.	Description	Quantity
28174	Label - Power to Platform, 230V	2
28235	Label - Power to Platform, 115V	2
40434	Label - Lanyard Anchorage	1
43658	Label - Power to Charger, 230V	1
44980	Label - Power to Charger, 115V	1
52475	Label - Transport Tie-down	3
72086	Label - Lifting Eye	1
72184	Cosmetic - Genie Runabout	2
72188	Label - Directional Arrows	2
82473	Label - Compartment Access	1
82481	Label - Battery Safety	1
82487	Label - Read the Manual	2
82495	Label - Brake Release Safety and Operation	1
82614	Label - Collision Hazard	1
82666	Label - Forklift Pocket	2
82835	Label - Max Capacity, 159 kg (models with AWP platform)	1
82836	Label - Emergency Lowering	1
82966	Label - Max Side Force, 445 N, ANSI	1
97810	Cosmetic - Genie GR-12	2
97811	Cosmetic - Genie GR-15	2
97812	Cosmetic - Genie GR-20	2


Part No.	Description	Quantity
97815	Label - Lower Mid-rail	6
97832	Label - Max Capacity, 227 kg, GR-12, GR-15 (models with standard platform)	1
97833	Label - Max Capacity, 159 kg, GR-20 (models with standard platform)	1
97873	Label - Max Capacity, Work Station Tray, 22 kg, GR-12, GR-15	1
97899	Label - Safety Chock	1
114334	Label - Electrocutation Hazard, Plug	1
114338	Label - Tip-over Hazard, Tilt Alarm	1
133015	Label - Electrocutation Hazard	1
133144	Label - Transport Diagram	2
133146	Label - Tip-over Hazard, Batteries	1
133147	Label - Tip-over Hazard, Limit Switch	1
137605	Label - Emergency Stop, Platform Control	1
137635	Label - Ground Control Panel	1
137636	Overlay - Platform Control Panel	1
137656	Label - Drive/Steer Direction, Platform Control	1
T106667	Label - Wheel Load, GR-12	4
T106668	Label - Wheel Load, GR-15	4
T106669	Label - Wheel Load, GR-20	4

Inspections

 Shading indicates decal is hidden from view, i.e., under covers.



Note: Platform decals may be in different locations on optional AWP platform.



Inspections



Do Not Operate Unless:

- You learn and practice the principles of safe machine operation contained in this operator's manual.
 - 1 Avoid hazardous situations.
 - 2 Always perform a pre-operation inspection.
 - 3 Always perform function tests prior to use.
 - 4 Inspect the workplace.
 - 5 **Only use the machine as it was intended.**

Fundamentals

The Operating Instructions section provides instructions for each aspect of machine operation. It is the operator's responsibility to follow all the safety rules and instructions in the operator's, safety and responsibilities manuals.

Using the machine for anything other than lifting personnel, along with their tools and materials, to an aerial work site is unsafe and dangerous.

Only trained and authorized personnel should be permitted to operate a machine. If more than one operator is expected to use a machine at different times in the same work shift, they must all be qualified operators and are all expected to follow all safety rules and instructions in the operator's, safety and responsibilities manuals. That means every new operator should perform a pre-operation inspection, function tests, and a workplace inspection before using the machine.

Operating Instructions


Emergency Stop

Push in the red Emergency Stop button to the off position at the ground or platform controls to stop all functions.

Repair any function that operates when either red Emergency Stop button is pushed in.

Emergency Lowering

- 1 Pull the Emergency lowering knob.



Operation From Ground

- 1 Be sure the battery pack is connected before operating the machine.
- 2 Turn the key switch to ground control.
- 3 Pull out the ground and platform red Emergency Stop buttons to the on position.

To Position Platform

- 1 At the control panel, press and hold the lift function enable button.
- 2 Press the platform up or down button.

Drive and steer functions are not available from the ground controls.

Operation From Platform

- 1 Turn the key switch to platform control.
- 2 Pull out the ground and platform red Emergency Stop buttons to the on position.
- 3 Be sure the battery pack is connected before operating the machine.

To Position Platform

- 1 Press and hold the high or low speed lift enable button.
- 2 Press the platform up or platform down button.



To Steer

- 1 Press and hold the drive/steer function enable switch on the control handle.
- 2 Turn the steer wheels with the thumb rocker switch located on the top of the control handle.



To Drive

- 1 Press and hold the drive/steer function enable switch on the control handle.
- 2 Increase speed: Slowly move the control handle off center.

Decrease speed: Slowly move the control handle toward center.

Stop: Return the control handle to center or release the function enable switch.

Use the color-coded direction arrows on the platform controls and on the platform to identify the direction the machine will travel.

Machine travel speed is restricted when the platform is raised.

Battery condition will affect machine performance. Machine drive speed and function speed will drop when the battery level indicator is flashing.

Operating Instructions

To select drive speed

The drive controls can operate in two different drive speed modes while in the stowed position. When the drive speed button light is on, slow drive speed mode is active. When the drive speed button light is off, fast drive speed mode is active.


Press the drive speed button to select the desired drive speed.



Note: When the platform is elevated, the drive speed button light is always on, indicating elevated drive speed.

Driving on a slope

Determine the slope and side slope ratings for the machine and determine the slope grade.



Maximum slope rating, stowed	30% (17°)
Maximum side slope rating, stowed	30% (17°)

Note: Slope rating is subject to ground conditions and adequate traction.

Press the drive speed button to the fast drive speed mode.

To determine the slope grade:

Measure the slope with a digital inclinometer OR use the following procedure.

You will need:

- carpenter's level
- straight piece of wood, at least 3 feet / 1 m long
- tape measure

Lay the piece of wood on the slope.

At the downhill end, lay the level on the top edge of the piece of wood and lift the end until the piece of wood is level.

While holding the piece of wood level, measure the distance from the bottom of the piece of wood to the ground.

Divide the tape measure distance (rise) by the length of the piece of wood (run) and multiply by 100.

Example:



$$\text{Run} = 12 \text{ ft (144 in) / 3.6 m}$$

$$\text{Rise} = 12 \text{ in / 0.3 m}$$

$$12 \text{ in} \div 144 \text{ in} = 0.083 \times 100 = 8.3\%$$


$$0.3 \text{ m} \div 3.6 \text{ m} = 0.083 \times 100 = 8.3\%$$

If the slope exceeds the maximum slope or side slope rating, the machine must be winched or transported up or down the slope. See Transport and Lifting section.


Operating Instructions

Operational indicator codes

If the platform controls LED or ground controls LCD diagnostic readout displays an operational indicator code such as LL, the fault condition must be repaired or removed before resuming machine operation. Push in and pull out the red Emergency Stop button to reset the system.



LED Readout



LCD Readout

Operational Indicator Codes

Code	Condition
LL	Off-Level
OL	Platform Overloaded
CH	Chassis Mode Operation
PHS	Pothole Guard Stuck

For further information, please consult the appropriate Genie Service Manual. A code and a description of a code can also be viewed at the ground controls LCD display.

To Extend and Retract Platform (if equipped)

- 1 Step on the platform extension release pedal.
- 2 Grasp the platform guard rails carefully and push to extend the platform.
- 3 Step on the platform extension release pedal and pull the guard rails to retract the platform.

Operation From Ground with the Platform Controls

Maintain safe distances between the operator, machine and fixed objects.




Be aware of the direction the machine will travel when using the platform controls.

Operating Instructions

Battery Level Indicator

Use the LED diagnostic readout to determine the battery level.

Note: When a blinking LO code appears on the platform controls LED diagnostic readout, the machine must be taken out of service and charged, otherwise all machines functions will be disabled.



Battery and Charger Instructions Observe and Obey:

- Do not use an external charger or booster battery.
- Charge the battery in a well-ventilated area.
- Use proper AC input voltage for charging as indicated on the charger.
- Use only a Genie authorized battery and charger.

Operating Instructions

To Charge Battery

- 1 Be sure the batteries are connected before charging the batteries.
- 2 Open the battery compartment. The compartment should remain open for the entire charging cycle.
- 3 Rest the cover against the chassis.
- 4 Lower the platform until the mast just contacts the battery cover.

⚠ Crushing hazard. Keep hands clear of the battery cover when lowering the platform.

- 5 Turn the key switch to the off position.
- 6 Be sure that the battery cable connections are tight and free of corrosion.

Maintenance - free batteries

- 7 Connect the battery charger to a grounded AC circuit.
- 8 The charger will indicate when the battery is fully charged.

Standard Batteries

- 7 Remove the battery vent caps and check the battery acid level. If necessary, add only enough distilled water to cover the plates. Do not overfill prior to the charge cycle.
- 8 Replace the battery vent caps.
- 9 Connect the battery charger to a grounded AC circuit.
- 10 The charger will indicate when the battery is fully charged.
- 11 Check the battery acid level when the charging cycle is complete. Replenish with distilled water to the bottom of the fill tube. Do not overfill.

Dry Battery Filling and Charging Instructions

- 1 Remove the battery vent caps and permanently remove the plastic seal from the battery vent openings.
- 2 Fill each cell with battery acid (electrolyte) until the level is sufficient to cover the plates.

Do not fill to maximum level until the battery charge cycle is complete. Overfilling can cause the battery acid to overflow during charging. Neutralize battery acid spills with baking soda and water.

- 3 Install the battery vent caps.
- 4 Charge the battery.
- 5 Check the battery acid level when the charging cycle is complete. Replenish with distilled water to the bottom of the fill tube. Do not overfill.

Transport and Lifting Instructions





Observe and Obey:

- ☑ Genie Industries provides this securement information as a recommendation. Drivers are solely responsible for making sure machines are properly secured and the correct trailer is selected pursuant to US Department of Transportation regulations, other localized regulations, and their company policy.
- ☑ Genie customers needing to containerize any lift or Genie product should source a qualified freight forwarder with expertise in preparing, loading and securing construction and lifting equipment for international shipment.
- ☑ Only qualified aerial lift operators should move the machine on or off the truck.
- ☑ The transport vehicle must be parked on a level surface.
- ☑ The transport vehicle must be secured to prevent rolling while the machine is being loaded.
- ☑ Be sure the vehicle capacity, loading surfaces and chains or straps are sufficient to withstand the machine weight. Genie lifts are very heavy relative to their size. See the serial label for the machine weight.
- ☑ The machine must be on a level surface or secured before releasing the brakes.

- ☑ Do not drive the machine on a slope that exceeds the uphill, downhill or side slope rating. See Driving on a Slope in the Operating Instructions section.
- ☑ If the slope of the transport vehicle exceeds the maximum slope rating, the machine must be loaded and unloaded using a winch as described in the brake release operation.

Brake Release Operation

- 1 Chock the wheels to prevent the machine from rolling. 
- 2 Be sure the winch line is properly secured to the drive chassis tie points and the path is clear of all obstructions.
- 3 Push in the black brake release knob to open the brake valve. 
- 4 Pump the red brake release pump knob.

After the machine is loaded:

- 1 Chock the wheels to prevent the machine from rolling.
- 2 Pull out the red Emergency Stop buttons at both the ground and platform controls to the on position, and turn the key switch to the platform position.
- 3 Press and hold the drive/steer function enable switch on the control handle. Move the control handle off center and immediately release it to reset the brakes.
- 4 Push the red Emergency Stop button at both the ground and platform controls to the off position.

Towing the GR-12, GR-15 and GR-20 is not recommended. If the machine must be towed, do not exceed 2 mph / 3.2 km/h.

Transport and Lifting Instructions

⚠ Securing to Truck or Trailer for Transit

Always chock the machine wheels in preparation for transport.

Always use the extension deck lock when the machine is transported.

Turn the key switch to the off position and remove the key before transporting.



Inspect the entire machine for loose or unsecured items.

Use the tie-down points on the chassis for anchoring down to the transport surface.

Use chains or straps of ample load capacity.

Use a minimum of 4 chains or straps.

Adjust the rigging to prevent damage to the chains.



Transport and Lifting Instructions



Observe and Obey:

- Only qualified riggers should rig and lift the machine.
- Be sure the crane capacity, loading surfaces and straps or lines are sufficient to withstand the machine weight. See the serial label for the machine weight.


⚠ Loading the Machine With a Crane

Use the lifting eye mounted on the rear mast column.

Make sure the mast is fully lowered.

Inspect the machine and remove any loose or unsecured items.

Always place the lifting hook through the lifting eye so that it points away from the machine.



Maintenance



Observe and Obey:

- ☑ Only routine maintenance items specified in this manual shall be performed by the operator.
- ☑ Scheduled maintenance inspections shall be completed by qualified service technicians, according to the manufacturer's specifications and the requirements specified in the responsibilities manual.
- ☑ Use only Genie approved replacement parts.

Maintenance Symbols Legend

The following symbols have been used in this manual to help communicate the intent of the instructions. When one or more of the symbols appears at the beginning of a maintenance procedure, it conveys the meaning below.



Indicates that tools will be required to perform this procedure.



Indicates that new parts will be required to perform this procedure.

Check the Hydraulic Oil Level



Maintaining the hydraulic oil at the proper levels is essential to machine operation. Improper hydraulic oil levels can damage hydraulic components. Daily checks allow the inspector to identify changes in oil level that might indicate the presence of hydraulic system problems.

Note: Perform this procedure with the platform in the stowed position.

- 1 Visually inspect the oil level in the hydraulic tank.
- ⦿ Result: The hydraulic oil level should be as marked on the tank.
- 2 Add oil if necessary. Do not overfill.

Hydraulic oil specifications

Hydraulic oil type	Chevron Rando HD equivalent
--------------------	-----------------------------

Maintenance

Check the Batteries



Proper battery condition is essential to good machine performance and operational safety. Improper fluid levels or damaged cables and connections can result in component damage and hazardous conditions.

Note: This procedure does not need to be performed on machines with sealed or maintenance - free batteries.

⚠ Electrocutation hazard. Contact with hot or live circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ Bodily injury hazard. Batteries contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

Note: Perform this test after fully charging the batteries.

- 1 Put on protective clothing and eye wear.
- 2 Be sure that the battery cable connections are tight and free of corrosion.
- 3 Be sure that the battery hold-down bars are in place and secure.

Note: Adding terminal protectors and a corrosion preventative sealant will help eliminate the corrosion on the battery terminals and cables.

Scheduled Maintenance

Maintenance performed quarterly, annually and every two years must be completed by a person trained and qualified to perform maintenance on this machine according to the procedures found in the service manual for this machine.

Machines that have been out of service for more than three months must receive the quarterly inspection before they are put back into service.

Specifications

GR-12

Height, working maximum	17 ft 4 in	5.3 m
Height, platform maximum	11 ft 4 in	3.5 m
Height, stowed maximum	62 in	1.57 m
Height, stowed maximum standard platform with work station tray	64 in	1.62 m
Width	29.5 in	74.9 cm
Length, stowed	53 in	1.35 m
Length with standard platform optional platform extension extended	73.3 in	1.85 m
Maximum capacity, standard platform	500 lbs	227 kg
Maximum capacity, AWP platform	350 lbs	159 kg
Maximum wind speed	28 mph	12.5 m/s
Turning radius (inside)	0 in	0 cm
Turning radius (outside)	52 in	132.1 cm
Ground clearance	2.5 in	6.5 cm
Weight (Machine weights vary with option configurations. See serial label for specific machine weight.)	1581 lbs	717 kg
Power source	4 Batteries, 6V 225AH	
Controls	Proportional	
AC outlet in platform	Standard	
Maximum hydraulic pressure (functions)	3000 psi	207 bar
Tire size	10 x 3 x 1 in 25.4 x 7.6 x 2.5 cm	

Airborne noise emissions

Sound pressure level at ground workstation	< 70 dBA
Sound pressure level at platform workstation	< 70 dBA
Vibration value does not exceed 2.5 m/s ²	

**Maximum slope rating,
stowed position** 30% (17°)

Maximum side slope rating 30% (17°)

Note: Slope rating is subject to ground conditions and adequate traction.

Drive speeds

Stowed, maximum	2.5 mph 40 ft/10.9 sec	4.0 km/h 12.2 m/10.9 sec
Platform raised, maximum	0.5 mph 40 ft/55 sec	0.8 km/h 12.2 m/55 sec

Floor loading information

Tire load, maximum	680 lbs	308 kg
Tire contact pressure	104.62 psi	7.36 kg/cm ² 721.3 kPa
Occupied floor pressure	191.52 psf	936 kg/m ² 9.18 kPa

Note: Floor loading information is approximate and does not incorporate different option configurations. It should be used only with adequate safety factors.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.



Specifications

GR-15

Height, working maximum	20 ft 7 in	6.3 m
Height, platform maximum	14 ft 8 in	4.5 m
Height, stowed maximum	62 in	1.57 m
Height, stowed maximum standard platform with work station tray	64 in	1.62 m
Width	29.5 in	74.9 cm
Length, stowed	53 in	1.35 m
Length with standard platform optional platform extension extended	73.3 in	1.85 m
Maximum capacity, standard platform	500 lbs	227 kg
Maximum capacity, AWP platform	350 lbs	159 kg
Maximum wind speed	28 mph	12.5 m/s
Turning radius (inside)	0 in	0 cm
Turning radius (outside)	52 in	132.1 cm
Ground clearance	2.5 in	6.5 cm
Weight (Machine weights vary with option configurations. See serial label for specific machine weight.)	2192 lbs	994 kg
Power source	4 Batteries, 6V 225AH	
Controls	Proportional	
AC outlet in platform	Standard	
Maximum hydraulic pressure (functions)	3000 psi	207 bar
Tire size	10 x 3 x 1 in 25.4 x 7.6 x 2.5 cm	

Airborne noise emissions

Sound pressure level at ground workstation	< 70 dBA
Sound pressure level at platform workstation	< 70 dBA
Vibration value does not exceed 2.5 m/s ²	

**Maximum slope rating,
stowed position** 30% (17°)

Maximum side slope rating 30% (17°)

Note: Slope rating is subject to ground conditions and adequate traction.

Drive speeds

Stowed, maximum	2.5 mph	4.0 km/h
	40 ft/10.9 sec	12.2 m/10.9 sec
Platform raised, maximum	0.5 mph	0.8 km/h
	40 ft/55 sec	12.2 m/55 sec

Floor loading information

Tire load, maximum	720 lbs	327 kg
Tire contact pressure	110.77 psi	7.79 kg/cm ² 763.73 kPa
Occupied floor pressure	247.68 psf	1210 kg/m ² 11.87 kPa

Note: Floor loading information is approximate and does not incorporate different option configurations. It should be used only with adequate safety factors.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.



Specifications

GR-20

Height, working maximum	25 ft 9 in	7.9 m
Height, platform maximum	19 ft 9 in	6.1 m
Height, stowed maximum	78 in	1.98 m
Width	31.5 in	80 cm
Length, stowed	53 in	1.35 m
Length with standard platform optional platform extension extended	73.3 in	1.86 m
Maximum capacity, standard platform	350 lbs	159 kg
Maximum capacity, AWP platform	350 lbs	159 kg
Maximum wind speed	28 mph	12.5 m/s
Turning radius (inside)	0 in	0 cm
Turning radius (outside)	53 in	134.6 cm
Ground clearance	2.5 in	6.5 cm
Weight (Machine weights vary with option configurations. See serial label for specific machine weight.)	2451 lbs	1112 kg
Power source	4 Batteries, 6V 225AH	
Controls	Proportional	
AC outlet in platform	Standard	
Maximum hydraulic pressure (functions)	3000 psi	207 bar
Tire size	10 x 3 x 1 in 25.4 x 7.6 x 2.5 cm	

Airborne noise emissions

Sound pressure level at ground workstation	< 70 dBA
Sound pressure level at platform workstation	< 70 dBA
Vibration value does not exceed 2.5 m/s ²	

**Maximum slope rating,
stowed position** 30% (17°)

Maximum side slope rating 30% (17°)

Note: Slope rating is subject to ground conditions and adequate traction.

Drive speeds

Stowed, maximum	2.5 mph	4.0 km/h
	40 ft/10.9 sec	12.2 m/10.9 sec
Platform raised, maximum	0.5 mph	0.8 km/h
	40 ft/55 sec	12.2 m/55 sec

Floor loading information

Tire load, maximum	870 lbs	395 kg
Tire contact pressure	133.85 psi	9.41 kg/cm ² 922.84 kPa
Occupied floor pressure	241.9 psf	1180 kg/m ² 11.57 kPa

Note: Floor loading information is approximate and does not incorporate different option configurations. It should be used only with adequate safety factors.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.



Specifications

Platform dimensions, all models (length x width)		
Standard platform	35 x 29.5 in	88.9 x 74.9 cm
Standard platform with extension	55 x 29.5 in	139.7 x 74.9 cm
Standard AWP platform	27 x 26 in	69 x 51 cm
Narrow AWP platform	26 x 20 in	66 x 51 cm

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice or obligation.



Genie Scandinavia

Phone +46 31 575100
Fax +46 31 579020

Genie France

Phone +33 (0)2 37 26 09 99
Fax +33 (0)2 37 26 09 98

Genie Iberica

Phone +34 93 579 5042
Fax +34 93 579 5059

Genie Germany

Phone 0800 180 9017
Phone +49 422 149 1818
Fax +49 422 149 1820

Genie U.K.

Phone +44 (0)1476 584333
Fax +44 (0)1476 584334

Genie Mexico City

Phone +52 55 5666 5242
Fax +52 55 5666 3241

Genie North America

Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.

Phone +61 7 3375 1660
Fax +61 7 3375 1002

Genie China

Phone +86 21 53852570
Fax +86 21 53852569

Genie Malaysia

Phone +65 98 480 775
Fax +65 67 533 544

Genie Japan

Phone +81 3 3453 6082
Fax +81 3 3453 6083

Genie Korea

Phone +82 25 587 267
Fax +82 25 583 910

Genie Brasil

Phone +55 11 41 665 755
Fax +55 11 41 665 754

Genie Holland

Phone +31 183 581 102
Fax +31 183 581 566

Distributed By: