

Assembly Instructions & Warranty Information The Bone™ & The Rough Rider™ Creepers

**PLEASE DO NOT DISCARD THIS PAPER!
YOU WILL NEED IT FOR FUTURE REFERENCE
AND/OR ANY WARRANTY ISSUES**

Congratulations and thank you for purchasing a member of the best family of mechanics creepers you can buy! For the first time you will be able to roll over obstacles that stop other creepers in their tracks, and be comfortable while doing so! With proper care this will be the last creeper you will ever buy. If you have any questions or comments, please call us at 800-266-3321 or 330-677-4030. Alternatively, you may visit our web site at www.bonecreeper.com.

Included in this box are:

- 1 Bone™ or Rough Rider™ body section (depending on model)
- 4 Bone™ or Rough Rider™ casters (depending on model)
- 1 bag containing sixteen each of 5/16" bolts and lock nuts

Assembly Instructions:

Place the creeper body decal side up on a table or the floor. Insert the sixteen 5/16" bolts into the holes in the body, then place a piece of tape over each wheel pod to secure the bolts to the body.

Flip the creeper over and slide the casters onto the bolts. Thread the nuts onto the bolts and hand tighten. With a 1/2" wrench or socket, carefully tighten the nuts just until the star washer is crushed. If the bolt spins while you turn the nut, you can use a 7/16" allen wrench to hold the bolt in place. **CAUTION: OVER TIGHTENING THE NUTS WILL CRACK THE CREEPER BODY AND VOID YOUR WARRANTY!**

Be sure to occasionally check the tightness of the nuts, as vibrations from rolling can cause them to gradually loosen. **Please see the reverse side of this sheet for caster care instructions.**

Limited Warranty Information:

Your Bone or Rough Rider creeper features a limited one year warranty on the body section and a limited lifetime warranty on the wheels and casters.

Our warranty covers manufacturer defects only, and we (Dale Adams Enterprises) reserve the right to determine the eligibility of all warranty claims.

Please note that the wheels on your creeper can be warranted separately from your metal casters, so if we do send you warranty replacements, please do not discard any part of your creeper until your replacement parts have arrived.

You can find more details on our warranty policy on the reverse side of this sheet.

CASTER CARE

We are very proud of our all-AMERICAN made casters. We feel our design is improved by not using a center rivet for the caster swivel assembly. Consequently we use a bolt and lock nut so the pre-load can be set properly on the bearings. You may have to adjust the pre-load from time to time. You will need a 9/16" socket or wrench to fit on the center nut. To do this, remove the wheel from the fork (using a 1/2" wrench for the Bone™ or 9/16" wrench for the Rough Rider™) and torque the nut until the swivel becomes tight (will not spin), then back off slowly until the swivel spins smoothly without any "slop". Tighten then loosen the same as you would a wheel bearing to make sure the ball bearings are properly seated. There will be a bit of a "break-in" period when your casters are new – if you find the swivel is a bit stiff it will loosen up with a bit of use.



IMPORTANT!

After using your creeper for a couple hours (and every month thereafter), please check the tightness of the center swivel nut. After the break-in period the swivel can become loose which will result in the loss of ball bearings. This is not covered under warranty!

Keep your casters clean! If you find that a lot of dirt and grease has built up on them, wash them with some Simple Green to get the grit and grime out of the bearings and axles. This will make sure that the creeper will last you for years on end! You should periodically add a few drops of oil to the ball bearing races and the axle bearing to ensure proper lubrication.

What Is Not Covered By Warranty?

Some examples of problems that we will NOT warranty:

- Broken or cracked creeper bodies from being hit, dropped or run over.
- Creeper bodies over one year old.
- Creeper bodies that have been cracked due to over tightening the casters .
- Caster forks and wheels that the user has allowed to become overly clogged with dirt and/or grease, causing the casters to no longer function properly (it is the customer's responsibility to care for their creepers).
- Any creeper body, caster fork or wheel that has been broken due to a customer hitting, running over, dropping, throwing, melting, or otherwise abusing.
- Any creeper body, caster fork or wheel that has been modified by the customer in any way, including: drilling, attaching non-Dale Adams Enterprises caster forks or wheels, lengthened by sawing, etc.
- Any damage from being loaded beyond its weight rating. (Bone: 300 lbs, Rough Rider: 400 lbs)

How To Care For Your Bone or Rough Rider Creeper

The Bone™ and The Rough Rider™ are high quality, 100% American made products. However, like all fine tools, they require a bit of care to ensure a lifetime of reliable use. Below you will find some tips and tricks to make sure that this will be the last creeper you will ever buy!

- Keep it clean! Using a creeper on a dirty floor will cause dirt and grease to build up on the casters. Over time this can cause the ball bearings to get jammed up with grit, as well as speed up possible tire degradation from rolling in grease and oil that can soften up the material. Also, a dirty creeper body will stain clean clothes! If you keep your creeper washed top and bottom with a light degreaser like Simple Green, it will perform like new for years! Be sure to clean around the swivels and axles of the casters.
- Do not drop your creeper! Set it down carefully on the ground. The Bone™ and Rough Rider™ creepers are made to be tough, but repeated abuse can cause the plastic on the body and wheels to crack or break, and such abuse is NOT covered by warranty! In addition, be aware that plastic becomes brittle in cold temperatures, so be extra careful if you are using your creeper in a cold shop or outside in the winter.
- Do not use your creeper as a ladder or stepping stool. If you stand on the top of the creeper with the wheels on the floor, you run the risk of the creeper rolling out from under you, which could result in serious injury!
- We stand behind our products with a limited one year warranty on the creeper body and lifetime on the wheels, but keep in mind that these only apply against manufacturer defects. Running over, dropping, hitting, overloading, allowing the casters to get too dirty or otherwise abusing your creeper will void these warranties!