

## Instruction Guide

John Deere 8000-8010 Series Window Step - (PN: 3402)

### NOTE! - When Installing This Application

*Do not tighten any bolts until all parts have been assembled to the tractor.*

1. Remove the cab air cleaner assembly.
2. Remove the shroud from the bottom of the muffler.
3. Remove the two bolts from the muffler support bracket located at the base of the muffler.
4. Fasten the **step mounting bracket** to the inside muffler support bracket; use the original bolts.
5. Replace the air filter and shroud.
6. Bolt the **front step** to the tractor frame with two 20mm x 45mm bolts and lock washers.
7. Bolt the **side step** to the **step mounting bracket** and to the outer end of the **front step**. Fasten with four 5/16" x 1" bolts, lock washers and nuts.
8. Fasten the two **handrails** to the **step** at the lower end and to the **step mounting bracket** at the upper end.
9. Tighten all bolts securely.
10. **After step installation, check turning radius of front tires for interference with step.**

