

Quick Spade Combo Instruction for fork hookup

- 1) Adjust skid loader forks and slide both forks into the two u channel brackets on the bottom side of the quick spade. (Opposite side of decal)
- 2) Using a 3/8 (2,000 lbs or more) Log Chain. Chain unit to the main frame of forks or to face plate of quick attach. (Chain not included)
- 3) Using a standard (ratchet style) 3/8 load binder. Tighten chain to prevent unit from sliding off the forks. (Binder not included)
- 4) All extra chain to be securely fastened to prevent injury or damage.
- 5) Always call for utility location before digging.
- 6) Read all Instructions of the power unit you are using in conjunction with this Quick Spade.
- 7) Do not place excess load on spade tip.
- 8) Total load not to exceed power unit (skid steer, tractor, ECT) maximum. (Quick Spade is designed for 30 horse power units.)

Quick Spade Combo Instruction for Bucket hookup

- 1) Leaving the top side up. (Decal showing top side) Slide the Quick Spade Combo onto the leading edge of bucket. (Must be center of bucket)
- 2) Using a 3/8 (2,000 lbs or more) Log Chain hook one end of the chain to the hook located on the bottom side of the Quick Spade Combo. Place chain around the bucket and hook opposite end of chain into the chain hook located on the top side of the Quick Spade Combo. (Chain not included)
- 3) Using a standard ratchet style 3/8 load binder. Tighten chain to prevent unit from sliding off the bucket. (Unit must be place in the center of bucket.) (Binder not included)
- 4) All extra chain to be securely fastened to prevent injury or damage.

- 5) Always call for utility location before digging.
- 6) Read all Instructions of the power unit you are using in conjunction with this Quick Spade Combo.
- 7) Do not place excess load on spade tip.
- 8) Total load not to exceed power unit (skid steer, tractor, ECT) maximum. (Quick Spade Combo is designed for 30 horse power units.)