

Handy-Spray - Assembly Instructions

1. Orient the handle so that the wires face the rear of the cart (A)
2. Put the tab of the frame in the lower hole of the handle (B)
3. Insert bolt through the hole in the frame and the upper hole in the handle. Secure with nut (C)
4. Connect blue spade connector to the negative terminal on the battery and the red connector to the positive side of the battery. (D)
5. Connect the flat two pin connector to the pump (E)
6. Insert tube fitting into the bracket hole and thread on nozzle holder (F).
7. Attach desired nozzle to nozzle holder and twist the nozzle to orient spray
8. Insert suction tube into the container (G)

