

PLASTICADE™ PORTABLE POST SIGN STANDS WITH RUBBER BASES

Hardware Provided:

3 ea. Hex Bolt Zinc 3/8 x 2-1/2

5 ea. Washer 3/8

3 ea. Locknut 3/8-16

To secure post to base: use 1 hex bolt, 1 locknut, and 1 washer

To secure sign: use 2 hex bolts, 2 locknuts, and 4 washers

Not Provided:

Rubber mallet (needed for 60 lb. and 90 lb. bases)



INSTRUCTIONS

1. Insert square post (end with holes on all four sides of post) in the rubber base square hole. You may need to use a rubber mallet to ensure post is inserted all the way down to the ground.
2. Use one 3/8 x 2-1/2 hex bolt, one washer, and one locknut to secure plastic post to rubber base at underside of base (see photo).
3. Use two 3/8 x 2-1/2 hex bolts, four washers, and two locknuts to attach sign



Plasticade.com

Part #8286 Rev. 1

PLASTICADE™ PORTABLE POST SIGN STANDS WITH RUBBER BASES

Hardware Provided:

3 ea. Hex Bolt Zinc 3/8 x 2-1/2

5 ea. Washer 3/8

3 ea. Locknut 3/8-16

To secure post to base: use 1 hex bolt, 1 locknut, and 1 washer

To secure sign: use 2 hex bolts, 2 locknuts, and 4 washers

Not Provided:

Rubber mallet (needed for 60 lb. and 90 lb. bases)



INSTRUCTIONS

1. Insert square post (end with holes on all four sides of post) in the rubber base square hole. You may need to use a rubber mallet to ensure post is inserted all the way down to the ground.
2. Use one 3/8 x 2-1/2 hex bolt, one washer, and one locknut to secure plastic post to rubber base at underside of base (see photo).
3. Use two 3/8 x 2-1/2 hex bolts, four washers, and two locknuts to attach sign



Plasticade.com

Part #8286 Rev. 1