




1

8

7

8



5



Back Side

3

4



6

Inside Holster

DIABLO

Numerical Representation:

- 1 - Safety switch
Bottom: All functions off
Middle: Tactical Flashlight
Top: Stun gun mode
- 2 - Stun gun activator
Only operates when Slider is in top position

- 3 - Charging cord input
- 4 - Charging indicator
- 5 - Charging cord (110v)
- 6 - Nylon holster
- 7 - Concealed stun probes
- 8 - Tactical flashlight

The device must be charged for 8-10 hours prior to initial use

Charging your device:

To charge, slide the Safety Switch into the off position (bottom). Insert the Power Cord into the Charging Cord Input and plug the cord directly into a 110v socket.

WARNING: Do not allow water or moisture to enter Charging Cord Input, Charging Cord or the electrical socket prior to, or during, charging.

Successful charging will show a green light on the Charging Indicator. Charge time varies for amount of battery drainage. Typical charge time should be 4-8 hours, but no longer than 16 hours.

Note: Avoid allowing the battery to completely drain before recharging. This can decrease the life cycle of the product. Decreasing light power, varying light outputs and slow stunning power will indicate a low battery. A fully charged device will operate, on constant flashlight mode, for up to 5 hours. A device which has used minimal flashlight mode can hold a stun gun charge for up to 2 months. Runtime will then vary by usage of stun gun/flashlight combination, frequency of use and other factors. It is recommended to charge the device regularly.

WARNING: Do not attempt to use or power the device while charging, as this could cause damage to the electrical outlet(s) and possibly result in fire.

To operate the flashlight:

Move the Safety Switch into the middle position. To turn off the flashlight, move the Safety Switch to the off (bottom) position.

Note: Do not move the Safety Switch to the top position to turn off the flashlight.

To operate the stun gun:

Move the Safety Switch into the top position. Then, firmly press the Stun Gun Activator button on the opposite side of the device. The Stun Gun Activator button will be inactive and disarmed if the Safety Switch is not in the top position.

To turn off the stun gun mode, move the Safety Switch to the off (bottom) position.

Shock time on assailant, and their effect, varies based on physical attributes, charge of device and other factors. The following are estimations of shock times, and their effect, on an assailant.

A quick touch will startle the assailant accompanied with pain, discomfort, muscular contraction and shock. Contact on an assailant for further periods can cause the assailant to fall, lose balance, lost muscle control, mental confusion, muscle spasms and/or disorientation.

This device does not cause permanent damage under normal circumstances. The user will not suffer a charge back when using the device on an assailant.

WARNING: Do not shock the assailant on the head, heart or in the area of any other major organs.



GUARD DOG Lifetime Warranty

This Guard Dog product has a lifetime warranty from the date of original purchase. Manufacturer warrants the product to be free from defective material or factory workmanship and agrees to repair or replace such products within normal use. Removal of battery pack, placement in moist/wet areas/surfaces, placement in extreme heat or cold, unintended use, mishandling, normal wear and tear, product life cycle use and/or self-inflicted damage to the device will void the warranty. Owner must provide receipt of purchase/ownership from an authorized Guard Dog Security retailer.