

LEA Y GUARDE ESTAS INSTRUCCIONES

PRECAUCIÓN: Lea y siga todas las instrucciones antes de operar el ventilador. No use el ventilador si alguna pieza estuviera dañada o faltara.
ADVERTENCIA: Para disminuir el riesgo de incendio o descarga eléctrica, no exponga este producto a la lluvia o a la humedad. Para disminuir el riesgo de incendio, no exponga este producto a la llama o a la chispa de ningún dispositivo de encendido.



NORMAS PARA UNA OPERACIÓN SEGURA:

1. Nunca introduzca los dedos ni ningún otro objeto por la rejilla de protección cuando el ventilador esté en funcionamiento.
2. Desconecte el ventilador si usted debe desplazarse de un lugar a otro.
3. Desconecte el ventilador si usted necesita la rejilla de protección para limpiarlo.
4. Asegúrese de que el ventilador esté bien asegurado en la posición de fijación antes de ponerlo en funcionamiento.


HIGH VELOCITY DRUM FAN

OWNER'S MANUAL

ADVERTENCIA: Asegúrese de que los tornillos de las rejillas de protección DEL FRENTE Y TRASERA estén bien enroscados en la posición de fijación antes de poner el ventilador en funcionamiento.

INSTRUCCIONES DE OPERACIÓN

PARA AJUSTAR EL FLUJO DE AIRE HACIA ATRÁS: Incline el cabezal del ventilador al ángulo deseado. El flujo de aire puede ajustarse con el aire acondicionado. Haga un ajuste para evitar el ruido del ventilador.
CONTROL DE VELOCIDAD: Gire el control de velocidad para seleccionar la velocidad deseada.
LIMPIEZA: Desconecte el ventilador antes de limpiarlo. Limpie el cabezal con un paño húmedo para eliminar la suciedad. No emplee una solución de limpieza que contenga alcohol o acetona. Limpie las palas.



MODEL
10256
(FE6-90DfOL)

| Modelo | Amperios A.T. | Fase | Altura |
|--------------|---------------|------|--------|
| 10256-90DfOL | 3.2 | 1 | 33" |

1-800-235-1448

READ AND SAVE THESE INSTRUCTIONS

CAUTION: Read and follow all instructions before Operating Fan. Do not use fan if any part is damaged or missing.

WARNING: To Reduce The Risk Of Fire Or Electrical Shock, Do Not Expose To Water Or Rain.

To Reduce The Risk Of Fire Or Electrical Shock, Do Not Use This Fan With Any Solid State Speed Control Device.

RULES FOR SAFE OPERATION:

1. Never insert fingers or any other objects through the grill guard when fan is in operation.
2. Disconnect the fan when moving from one location to another.
3. Disconnect the fan when removing guards for cleaning.
4. Be sure fan is on a stable, flat surface when in operation.
5. DO NOT use fan in windows. Rain and moisture may create electrical hazard.

CAUTION: Do not alter the Fan's assembly.

WARNING: Be sure FRONT and rear GUARD screws are completely screwed down in locking position before operation.

If the supply cord is damaged, it must be replaced by a special cord or service agent or a similarly qualified person in order to avoid a hazard.

OPERATING INSTRUCTIONS

TO ADJUST AIRFLOW UPWARD OR DOWNWARD: Tilt fan head to the desired angle. This high velocity fan can be used alone or in conjunction with air conditioning. Rotating the fan head upward serves to pull air from the floor and circulate it throughout the entire room.

SPEED CONTROL: Rotate SWITCH to LOW AND HIGH speeds for respective air velocity. It is normal for the motor to feel warm to touch after continuous operation. This fan features a thermostat that will automatically shut off should it overheat for any reason. If this happens, immediately unplug the fan from the outlet.

CLEANING

WARNING: Unplug from electrical supply source before cleaning:

1. Use soft damp cloth to clean. Then wipe with dry cloth.
2. Do not use a cleaning solution that is harmful to paints or plastics.
3. Do not bend the blades.
4. The motor bearings are permanently sealed and do not require additional lubrication.

IMPORTANT: SURGES IN ELECTRICAL POWER OR EXCESSIVE HEAT MAY CAUSE THE FAN TO TURN OFF. WAIT APPROXIMATELY 15 MINUTES FOR THE FAN TO RESUME OPERATION.

| MODEL | Watts (W) | | Amps (A) | | Volts |
|-----------------------|-------------|------|------------|------|------------|
| | Low | High | Low | High | |
| 10256 (FE6-90DFOL) | 320 | 370 | 2.75 | 3.2 | 120V~ 60Hz |

If you should have any operation questions, contact us toll-tree at 1-800-295-4448.

Place
Stamp
Here

ALOHA HOUSEWARES, INC.
P. O. BOX 5627
ARLINGTON, TEXAS 76005

SERVICE REQUEST CARD

This card must be completed and returned with your fan for service and is considered authorization for ALOHA HOUSEWARES to make all repairs covered under this warranty. Please do not return to the store before you call our toll free number (1-800-295-4448).

Owner Name _____

Street Address _____

City _____ State _____ Zip _____

Home Phone _____ Work Phone _____

Today's Date _____ Date Purchased _____

Model No.: _____ Code _____

ALOHA HOUSEWARES is NOT responsible for any repairs arising from damage in transit. Please pack the fan in its original package or a similar package that provides an equal degree of protection.

