


FlowPro

HIGH VELOCITY DRUM FAN OWNER'S MANUAL



MODEL

10384

(FE7-75D3fOL)

**DIRECT DRIVE DRUM FAN
ASSEMBLY AND OPERATING INSTRUCTIONS**

READ AND SAVE THESE INSTRUCTIONS

VERY IMPORTANT SAFETY INFORMATION: Always follow these instructions to avoid bodily injury.

DANGER: Do not submerge motor or allow motor to be exposed to water. Personal injury and/or death could result.

WARNING: Risk of electrical shock---This fan is supplied with a grounding conductor and **GFCI** type plug. To reduce the risk of electrical shock, be certain that it is connected only to a **PROPERLY** grounded receptacle.

WARNING: Electric shock hazards---may cause severe personal injury or death. For your safety, turn off the electrical power supply at the service entrance before installing, moving, or servicing your fan to avoid any possible electrical shock hazards. Never make adjustments to the fan when in power is on. When plugging in fan, adjusting head and changing speeds---**NEVER** stand in water. This practice can result in a dangerous or even fatal electric shock.

DANGER: Never handle the fan or motor with wet hands or when standing on wet or damp surface or in water. Fatal electrical shock could occur.

WARNING: Electric shock hazards---may cause severe personal injury or death. **DO NOT UNDER ANY CIRCUMSTANCES REMOVE THE POWER SUPPLY CORD GROUND PRONG OR GROUND FAULT UNIT.** For your personal safety, the fan must be grounded. The fan is equipped with a power supply with ground fault circuit interrupting device. Removal or tampering of power cord will void warranty.

NEVER USE AN EXTENSION CORD TO CONNECT THE FAN TO AN OUTLET. All installations must be made into a grounded outlet.

UNPLUG THE FAN WHEN NOT IN USE.

WARNING: To reduce the risk of fire or electrical shock, do not use this fan with any solid state speed control device. This appliance has a 3-prong plug. To reduce the risk of electrical shock, this plug is intended to fit in an outlet only one way. If this does not fit outlet, contact a qualified electrician. Do not attempt to bypass this procedure.

CAUTION: Read and follow all instructions before operating fan. Do not use fan if any part is damaged.

RULE FOR SAFE OPERATION:

- Never insert fingers or any other objects through the grill guard when fan is in operation.
- Disconnect the fan when moving from one location to another.
- Disconnect the fan when removing guards for cleaning.
- Be sure fan is on a stable, flat surface when in operation.
- DO NOT use fan in windows. Rain may create electrical hazard.

OPERATING INSTRUCTIONS:

WARNING: Electric shock hazards---may cause severe personal injury or death. For your safety, turn off the electrical power supply at the service entrance before assembling, installing, moving, or servicing your fan to avoid any possible electrical shock hazards.

1. Place fan in desired position.
2. Turn on fan to desired speed.

WARNING: To prevent electric shock---DO NOT attempt the following operations with the fan on.

SPEED CONTROL: Pressing the SWITCH at the back of the fan to **Low** or **High** for desired air movement.

CLEANING

WARNING: Electric shock hazard--Unplug from electrical supply source before cleaning.

- Use soft damp cloth to clean, then wipe with dry cloth.
- Do not use harmful cleaner to paints or plastics.
- Do not bend blades.
- The motor bearings are permanently sealed and do not require additional lubrication.

IMPORTANT: SURGES IN ELECTRICAL POWER OR EXCESSIVE HEAT MAY CAUSE THE FAN TO TURN OFF. WAIT APPROXIMATELY 15 MINUTES FOR THE FAN TO RESUME OPERATION.

MODEL	Watts (W)		Amps (A)		Volts
	Low	High	Low	High	
10384 (FE7-75D3fOL)	280	320	2.4	2.75	120V~ 60Hz

If you should have any operation questions, contact us toll-tree at 1-800-295-4448.