


Wiring Diagram

Pierce Arrow Inc.

ROUND SOLENOID ASSEMBLY



PS528C
ROUND SOLENOID
ASSEMBLY

WIRING CHART

Connect the wires to the corresponding signs.


- A** Armature Post
- 1** Field 1
- 2** Field 2
- +** 12V

PS528C MOTOR

Use the Pierce PS534H or PS534CH Motor on the PS528C round solenoid assembly.



PS534H
Pierce 12V Motor

<p>WIRING DESCRIPTION</p> <p>This chart depicts wiring from a Pierce PS528C round solenoid assembly to the Pierce PS534H or PS534CH 12V motor. Use #2 or #4 gauge wiring.</p>	 <p>Pierce Arrow Inc. Manufacturing recovery equipment and winches since 1976.</p>	
	<p>PRODUCT DESCRIPTION</p> <p>ROUND SOLENOID ASSEMBLY</p>	
<p>CATEGORY</p> <p>WINCH PARTS</p>	<p>PART NUMBER</p> <p>PS528C</p>	<p>CONTACT</p> <p>Pierce Arrow Inc. 549 U.S. HWY 287 S. Henrietta, TX 76365 www.piercearrow.us 1-800-658-6301</p>