




KLUTCH AVENGER W500

OWNER'S MANUAL



WARNING:

Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item# 38487

Thank you very much for choosing a Klutch product! For future reference, please complete the owner's record below:

Model: _____ Purchase Date: _____

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it.

This illumination tool is designed for certain applications only. The distributor cannot be responsible for issues arising from modification. We strongly recommend this illumination tool not be modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the illumination tool until you have first contacted the distributor to determine if it can or should be performed on the product.

For technical questions please call **1-800-222-5381**.

SPECS

Technical Parameter	25%	50%	Mode	SOS
Output			500 Lumens	/
Run Time	4h	2.5h	1.5h	
Beam Distance	30m			
Impact Resistance	1.5m			
Water-proof Grade	IPX-8			
Accessories	Holster, Lanyard, Spare O-Ring			

The Avenger W500 includes a superbright CREE XM-L T6 LED bulb, along with a rechargeable battery and charger.

GENERAL SAFETY RULES



WARNING: Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury.



CAUTION: Do not allow persons to operate or assemble this illumination tool until they have read this manual and have developed a thorough understanding of how the tool works.



WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

SAVE THESE INSTRUCTIONS

ILLUMINATION TOOL USE AND CARE

Do not modify the illumination tool in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the **illumination tool** was designed.

Always check of damaged or worn out parts before using the illumination tool. Broken parts will affect the **illumination tool** operation. Replace or repair damaged or worn parts immediately.

Store idle illumination tool. When **illumination tool** is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.

Frequently clean the conduction contact surface of the illumination tool to ensure best performance.


When the illumination tool is not to be used for a long period of time. Take out the battery.

After long period of use. Inspect the O-rings in the flashlight for damage. If damage replace the O-rings to ensure to maintain the water-proof performance of the illumination tool.

BATTERY REPLACEMENT


FLEX-POWER Operation — the Avenger W500 includes Flex-Power technology. This technology allows you to power the illumination tool two ways, first with the included rechargeable battery (included), second with 2 CR123 Batteries.

1. Unscrew tail cap counterclockwise and remove.
2. If replacing a battery. Remove old battery and dispose properly
3. Insert battery of choice. Either the rechargeable included or two CR123 batteries.
4. Replace tail cap by screwing on clockwise. Press tail cap button to test.



OPERATION

1. Press tail switch to turn on the illumination tool.
2. Move magnetic switch to select one of five modes (100%, 50%, 25%, Strobe and SOS).
3. Press tail switch to turn off the illumination tool.



MAINTENANCE

- **Maintain your illumination tool.** It is recommended that the general condition of any **illumination tool** be examined before it is used. Keep your **illumination tool** in good repair by adopting a program of consistent repair and maintenance. Have necessary repairs made by qualified service personnel.
- Wipe with a clean, dry cloth.
- After a long period of use, inspect the O-rings in the flashlight for damage. If damage is evident, replace the O-rings to maintain the waterproof performance of the illumination tool.

For replacement parts and technical questions, please call **1-800-222-5381**.

WARRANTY

1-year limited warranty



Distributed by
Northern Tool + Equipment Co., Inc.
Burnsville, Minnesota 55306
NorthernTool.com
Made in China