


STEEL BARREL TRUCK



TIPPING CART FORWARD AGAINST BARREL WILL FORCE SPRING LOADED BAR TO UNLOCK AND WILL AUTOMATICALLY DROP TO LIP OF BARREL. LOCK WILL AUTOMATICALLY RELEASE WHEN BARREL IS LOWERED TO FLOOR. SHOES ARE INTERCHANGEABLE WITH EACH OTHER FOR DIFFERENT WIDTH BARRELS. KEEP LIGHTLY GREASED TO PREVENT CHIME HOOK FROM STICKING.