

Instructions: Deluxe Travel Trailer Cover

⚠️WARNING!

Installation is best done with two people. **Never install on a windy day or when your trailer roof is slippery. Please take care when you are on a ladder or the roof.**

CAUTION

Please consult your RV owners manual.

Tools Needed:

Scissors

Matches or lighter (optional)

Screwdriver (usually Phillips head) for roof antennas

Installation

1. Cover or tape any sharp edges on your trailer that could wear against your cover. Be sure to lower any roof antennas.

2. Unroll the cover next to your trailer. The Classic logo on your cover should be to the front of your RV and facing the outside. Unzip the passenger side and back panels.

3. On smaller trailers your cover can be installed with ladders or by pulling it over the sides with tie ropes. (Be sure not to snag the cover on the top).

On larger trailers it's easiest to install your cover from the roof. Carefully climb up on the roof pulling the cover front with you. Lower the front of your cover down over the front of your trailer then carefully move toward the back pulling the cover and letting it fall down the sides of your trailer.

Climb down the rear ladder and locate the ladder cap. (The cap helps keep the top of the ladder from stressing the cover). Fit it over the ladder top and attach it to the rungs with the hook and loop straps. Now pull the back end of the cover down the back of the trailer.



4. Zip all the panels closed on your cover then pull the elasticized corners down over both bumpers of the trailer.

5. Tie an end of the supplied rope onto one of the D-rings along the bottom hem. Put a small rock in the provided toss bag, close the top and tie the free end of the rope to the bag D-ring. Now toss the bag and rope under your trailer to the D-ring on the opposite side. Take the rope off the bag and, allowing enough to make a knot, cut it off and tie it to the D-ring. Repeat with the remaining D-rings.

To keep the rope ends from fraying you can carefully melt the ends with a match or lighter.

6. Adjust the strap length on the white tension panels across the front and back to fit your trailer. Don't over tighten—the straps should be snug, not drum tight. To attach the straps into the side-release buckles just insert the clip into the buckle. To release the buckle press the buttons on both sides and pull the clip out of the buckle.

Use and Storage

Your cover can be unzipped for access to the passenger side and rear. The panels can be rolled up and held in place with the hook and loop straps toward the top of each panel.

A handy storage bag is provided. To fit it in the bag fold your cover and roll the cover tightly rather than stuffing

it. Never store a wet cover in the storage bag or confined area as the cover can be damaged by mildew.

Care

Spot clean with water, a mild soap and a sponge. Don't use abrasive cleaners or brushes.

Three Year Limited Warranty

If this cover fails due to a defect in workmanship and materials within three years from the date of purchase Classic Accessories will repair or replace it free of charge.

Trailer or towing your trailer with your cover on will invalidate the warranty

This warranty gives you specific rights and you may also have other rights which vary from state to state.



Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com