



12FT. X 12FT. STRAIGHT LEG CANOPY

OWNER'S MANUAL



WARNING:

Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item# 47511

Thank you very much for choosing a Strongway product! For future reference, please complete the owner's record below:

Model: _____ Purchase Date: _____

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it.

This canopy is designed for certain applications only. The distributor cannot be responsible for issues arising from modification. We strongly recommend this canopy not be modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the canopy until you have first contacted the distributor to determine if it can or should be performed on the product.

For technical questions please call **1-800-222-5381**.

INTENDED USE

Ideal for backyard parties, camping, tailgating and more.

TECHNICAL SPECIFICATIONS

Item	Description
Capacity	144 sq. ft. capacity
Construction	Integrated steel frame (one piece frame)
Dimensions	12ft. x 12ft. (UPF 50+)

GENERAL SAFETY RULES



WARNING: Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury.



CAUTION: Do not allow persons to operate or assemble this canopy until they have read this manual and have developed a thorough understanding of how the canopy works.



WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY CONSIDERATIONS

CANOPY USE AND CARE

-  **WARNING:** To avoid personal injury fully read and understand the following instructions before each use. Do not modify the canopy in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the **canopy** was designed.
- **Always check of damaged or worn out parts before using the canopy.** Broken parts will affect the canopy operation. Replace or repair damaged or worn parts immediately.
- **Store idle canopy.** When canopy is not in use, store it inside, and in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.
- **Fully read and understand this manual before assembly of the canopy.** Keep this manual with the canopy and accessible for each use.
- **Adult assembly only.** Do not allow children or people with reduced mental capacity or under the influence of drugs or alcohol to assemble this canopy.
- **Low to moderate wind only.** Do not assemble this canopy where it could encounter high winds. There is a danger of it being carried by the wind and it could cause personal injury if it becomes untethered. Ensure the canopy is properly anchored at all times.
- **Sunburn Warning.** This canopy only provides sun ray protection in the shade area. Due to the sun's position this may not be directly under the canopy. Also, there may be additional sun exposure off of reflective surfaces that cannot be prevented by this canopy. Ensure that users are aware of the sun's position, wear sunscreen, and actively monitor themselves for overexposure to the sun.

 **WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.** This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

ASSEMBLY


STEP 1: Verify Package Contents

Verify package contents by emptying contents of bag(s) and confirming all parts are included and undamaged.

NOTE: Find the stakes in their pocket inside your carry bag. Verify all contents before you set it up.


STEP 2: Pull and extend the frame

- 1) Select a smooth level site and spread out your canopy.
 - 2) With two persons standing at diagonal corners of the structure, have each grab a corner leg and slowly unfold the frame, enough to allow both persons to comfortably drape the top over the frame.
- Tip: Do not unfold the frame completely. This will allow easier fit for draping shelter top over frame.



STEP 2: Cover the frame with fabric shell

- 1) Center top over the frame, lining up corners with frame corners. Attach nylon fasteners on the corners ONLY.
- 2) After fitting each corner of gazebo to frame, pull up sliding mold located on upper portion of leg until push button snaps into place.
- 3) Secure sides of canopy to frame with nylon fasteners provided (2 on each side). Canopy has been designed to have a tight fit over frame.
- 4) Secure all remaining nylon fasteners, located on underside of canopy top.



STEP 3: Extend the legs and stake canopy

- 1) Adjust desired height by sliding legs upward until push button locking into place. Raise each leg one notch at a time, making sure all four legs are level before proceeding to the next notch.
- 2) Stake canopy by driving stakes through the holes at the foot of each leg, webbing loops.

Tip: Use additional weights (sand bags, other heavy objects) on each foot or place legs twelve inches down into sand to help secure set up for beach use. Stakes alone will not secure canopy in sand or soft soil.

- 3) To stabilize the canopy, unroll the guy rope attached to the webbing loops. Make a loop at the opposite end of the guy line using the plastic slider and place the loop over the canopy stake. Drive the stake into the ground to secure. Adjust the plastic slider to tighten the guy rope. Repeat for each guy rope.



DISASSEMBLY INSTRUCTIONS

Store all poles and stakes in their corresponding bags to prevent possible tearing or damage to fabric.

STEP 1: Remove the stakes

Carefully remove stakes by pulling out the hook ends.

Remove excess soil from the stakes and store them in their bag.

STEP 2: Take down the canopy

A) Remove any accessories if installed. Fold for storage.

B) Press the push button located in the middle of each leg, and carefully lower each leg making sure all legs are level before proceeding. Repeat until frame is lowered to ground.

C) Remember the fasteners are inside roofline, on side scissors bars, and at corners. Detach all fasteners and remove fabric completely off frame and fold for storing.

NEVER STORE FABRIC ON FRAME. YOU MAY DAMAGE FABRIC, FRAME, OR BOTH.

D) Press the push buttons found on each leg at each upper corner of frame, making sure that all sides are detached from snap button. Slowly slide roof line downward while walking in. This should collapse frame completely.

STEP 3: Store in carry bag

A) To prolong the life of your canopy, you will want to store it correctly. Please folded frame “feet first” toward carry bag wheels.

B) Return stakes into their stake bag and place along side frame

C) Lastly, place folded fabric on top of frame legs, making sure all is completely tucked inside carry bag. Carefully zip carry bag closed.

Note: After fully packing the bag, double check the bag contents and surrounding area for loose parts.)

MAINTENANCE

- **Maintain your canopy.** It is recommended that the general condition of any **canopy** be examined before it is used. Keep your **canopy** in good repair by adopting a program of conscientious repair and maintenance. Have necessary repairs made by qualified service personnel.
- **Store idle canopy.** When **canopy** is not in use, store it inside, and in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.
- **Always check of damaged or worn out parts before using the canopy.** Broken parts will affect the **canopy** operation. Replace or repair damaged or worn parts immediately.


DIAGRAM AND PARTS LIST



CTOP-1212G



FPTY-1212G



CBAG-1212G



SSET-1212G

Part#	Description	Qty.	Part#	Description	Qty.
CTOP-1212G	Canopy top with integrated guy lines	1	FPTY-1212G	Frame	1
CBAG-1212G	Carry bag	1	SSET-1212G	Stake	8

For replacement parts and technical questions, please call **1-800-222-5381**.

Limited Warranty

Limited Warranty

Northern Tool and Equipment Company, Inc. ("We" or "Us") warrants to the original purchaser only ("You" or "Your") that the Strongway product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of one year from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

Obligations of Purchaser

You must retain Your product purchase receipt to verify date of purchase and that You are the original purchaser. To make a warranty claim, contact Us at 1-800-222-5381, identify the product by make and model number, and follow the claim instructions that will be provided. The product and the purchase receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs or costs related to Your return visit to a retail store.

Remedy Limits

Product replacement or a refund of the purchase price is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for: service or labor charges or damage to Your property incurred in removing or replacing the product; any damages, including, without limitation, damages to tangible personal property or personal injury, related to Your improper use, installation, or maintenance of the product; or any indirect, incidental or consequential damages of any kind for any reason.

Assumption of Risk

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

Governing Law

This limited warranty gives You specific legal rights, and You also may have other rights which vary from state to state. Some states do not allow limitations or exclusions on implied warranties or incidental or consequential damages, so the above limitations may not apply to You. This limited warranty is governed by the laws of the State of Minnesota, without regard to rules pertaining to conflicts of law. The state courts located in Dakota County, Minnesota shall have exclusive jurisdiction for any disputes relating to this warranty.



Distributed by
Northern Tool + Equipment Co., Inc.
Burnsville, Minnesota 55306
NorthernTool.com
Made in China