Pneumatic Roller Seat with Tool Tray

Owner's Manual



WARNING: Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item #52967

SAVE THESE INSTRUCTIONS

Thank you very much for choosing an Ironton® product!

For future reference, please complete the owner's record below:

Serial Number/Lot Date Code: _____

Purchase Date: _____

Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This roller seat is designed for certain applications only. Northern Tool & Equipment is not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

For technical questions, please call **1-800-222-5381**.

Table of Contents

Intended Use **4**
Technical Specifications **4**
Important Safety Information **4**
Specific Operation Warnings **5**
Main Parts of Product **5**
Assembly Instructions **6**
Parts Diagram **7**
Parts List **7**
Replacement Parts **7**
Limited Warranty **8**

Intended Use

This Ironton Pneumatic Roller Seat with Tool Tray has one-hand pneumatic height adjustment which makes it easy to find the right position. It has an extra padded seat for comfort and 5 swivel casters for easy maneuvering and increased stability. The seat comes with a 5 section storage tray for tools and parts.

Technical Specifications

Property	Specification
Dimensions W x H (in.)	15.16 x 15.16
Caster Type	Swivel
Height Range (in.)	15 3/4 to 19 1/2
Material	Steel
Rated Load Capacity	300 lbs.

Important Safety Information

⚠WARNING

- Read and understand all instructions. Failure to follow all instructions may result in serious injury or property damage.
- The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that could occur. Exercise common sense and caution when using this seat. Always be aware of the environment and ensure that the seat is used in a safe and responsible manner.
- Do not allow persons to operate or assemble the seat until they have read this manual and have developed a thorough understanding of how it works.
- Do not modify this seat in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the product. There are specific applications for which the product was designed.
- Use the right tool for the job. DO NOT attempt to force small equipment to do the work of larger industrial equipment. There are certain applications for which this equipment was designed. It will be safer and do a better job at the capacity for which it was intended. DO NOT use this equipment for a purpose for which it was not intended.
- Industrial or commercial applications must follow OSHA requirements.

⚠WARNING

This product may contain chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

⚠WARNING

PERSONAL SAFETY

- Wear the proper personal protective equipment when necessary. Use ANSIZ87.1 compliant safety goggles (not safety glasses) with side shields, or when needed, a face shield. Use a dust mask in dusty work conditions. Also use non-skid safety shoes, hardhat, gloves, dust collection systems, and hearing protection when appropriate. This applies to all persons in the work area.

- Do not overreach. Keep proper footing and balance at all times.

⚠CAUTION

SEAT USE AND CARE

- Do not force the seat. Products are safer and do a better job when used in the manner for which they are designed. Plan your work, and use the correct product for the job.
- Check for damaged parts before each use. Carefully check that the seat will operate properly and perform its intended function. Replace damaged or worn parts immediately. Never operate the seat with a damaged part.
- Store the seat when it is not in use. Store it in a dry, secure place out of the reach of children. Inspect the tool for good working condition prior to storage and before re-use.
- Weight capacity and other product capabilities apply to properly and completely assembled product only.
- Use only accessories that are recommended by the manufacturer for use with your seat. Accessories that may be suitable for one product may create a risk of injury when used with another tool. Never use an accessory that has a lower operating speed or operating pressure than the tool itself.

Specific Operation Warnings

⚠WARNING


- Do not place under automobile tires to move or reposition a vehicle.
- Do not exceed the rated load capacity.
- Do not use as a toy or skateboard.
- Do not stand on or use as a stepping device.
- Inspect for damages or defects before using.
- Do not use if any part of the support structure is damaged, split, or cracked.
- When not in use, store in a secure place.
- Always store in an upright position.
- Keep out of reach of children.

Main Parts of Product


Reference	Subassembly
1	Seat
2	Air cylinder
3	Base
4	Caster

Assembly Instructions

1. Mount the casters and then slide the painted end of the air cylinder into the hole in the center of the base.




2. Place the seat on top of the unpainted end of the air cylinder.



3. Lock the air cylinder in place by slowly adding your weight to the seat. Remain seated for approximately 10 seconds.

Parts Diagram



Parts List

Reference	Description	Quantity
1	Seat	1
2	Air cylinder	1
3	Base	1
4	Caster	5
5	Nut	5
6	Spring washer	5

Replacement Parts

- For replacement parts and technical questions, please call Customer Service at **1-800-222-5381**.
- Not all product components are available for replacement. The illustrations provided are a convenient reference to the location and position of parts in the assembly sequence.
- When ordering parts, the following information will be required: item description, item model number, item serial number/item lot date code, and the replacement part reference number.
- The distributor reserves the rights to make design changes and or improvements to product lines and manuals without notice.

Limited Warranty

Northern Tool and Equipment Company, Inc. ("We" or '"Us") warrants to the original purchaser only ("You" or “Your”) that the Ironton product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of one year from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product or product component without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

Obligations of Purchaser

You must retain Your product purchase receipt to verify date of purchase and that You are the original purchaser. To make a warranty claim, contact Us at 1-800-222-5381, identify the product by make and model number, and follow the claim instructions that will be provided. The product and the purchase receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs or costs related to Your return visit to a retail store.

Remedy Limits

Product replacement or a refund of the purchase price is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for: service or labor charges or damage to Your property incurred in removing or replacing the product; any damages, including, without limitation, damages to tangible personal property or personal injury, related to Your improper use, installation, or maintenance of the product or product component; or any indirect, incidental or consequential damages of any kind for any reason.

Assumption of Risk

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

Governing Law

This limited warranty gives You specific legal rights, and You also may have other rights which vary from state to state. Some states do not allow limitations or exclusions on implied warranties or incidental or consequential damages, so the above limitations may not apply to You. This limited warranty is governed by the laws of the State of Minnesota, without regard to rules pertaining to conflicts of law. The state courts located in Dakota County, Minnesota shall have exclusive jurisdiction for any disputes relating to this warranty.



Distributed by:
Northern Tool & Equipment Company, Inc.
Burnsville, Minnesota 55306
www.northerntool.com

Made in China