


TITAN

Propane Heat Gun

51886



Parts and Accessories:

1. Pushbutton Ignition / Temperature Dial
2. Valve
3. Rotating Collar
4. Removable Heat Sink Cage
5. Spreader Nozzle
6. Deflector Nozzle

When unpacking, make sure that the product is intact and undamaged. All damaged parts must be repaired or replaced as needed prior to use of this product. Failure to do so may result in serious personal injury or property damage. If any part is missing or broken, please call 1-800-386-0191 for assistance as soon as possible.

WARNING

It is the owner and/or operator's responsibility to study all **WARNINGS**, operating, prior to use of this product.

The owner/operator shall retain product instructions for future reference.

This tool is for use with Propane which is a flammable product. Failure to comply with warnings and instructions may result in explosion, fire, cause property damage, serious injury or death.

Read and comply with all warning and instructions in this manual. Do not operate prior to reading this manual and familiarizing yourself with this tool.

Use only with Propane cylinders that are specifically designated for use with torches and heat guns.

Keep out of reach of children. Do not point heat gun towards face, other persons or flammable objects.

Disconnect heat gun from propane cylinder when not in use.

Do not attempt to modify the construction of this tool and never use unapproved accessories or fuel.

Use caution when using outdoors on windy days. Windy conditions may cause sparks or carry the heat towards you.

DO NOT use heat gun if damaged, leaking or malfunctioning.

Never use on or near combustibles. Use extra caution near motorized vehicles and other gasoline powered objects. Heating a surface may cause heat to be conducted to adjoining surfaces. Be aware of surrounding areas and always check to make sure no unintended parts or materials are being heated.

Use only in a well ventilated area. Never use in confined spaces. Avoid the fumes from fluxes, lead based paint, and all metal heating operations. Use extra caution to avoid fumes from cadmium plating and galvanized metal. It is recommended to remove these coating by sanding or filing prior to heating.

WARNING (CONTINUED)

Always wear safety glasses, protective gloves and handle heated work with proper tools.

CAUTION: The heat gun nozzle and accessories get extremely hot during use! Take precautions to protect yourself and other from accidental burns.

When in use, do not place heat gun on uneven surfaces. Always make certain heat gun is placed on a level surface to reduce the risk of tipping.

Never leave unattended when heat gun is lit.

Never attempt to heat / repair gasoline tanks, chemical drums, aerosol cans or compressed gas containers that held flammable liquids, gas or chemicals even after they have been emptied.

Be careful when thawing frozen pipes to not overheat surrounding materials. Use heat shield if necessary.

Always keep a fire extinguisher and bucket of water near work area where heat gun is being used.

It is recommended to turn off heat gun for a brief period after each hour of use.

OPERATING INSTRUCTIONS


CONNECTING TO A PROPANE CYLINDER:

Only connect to 1" thread disposable propane cylinders, outdoors in a well ventilated area.

1. Ensure that the ignition/temperature knob (A) is in the OFF position (turned fully clockwise).
2. With the propane cylinder in the upright position, gently thread the propane cylinder (B) into the heat gun valve (C).

CAUTION: Threads should be hand tight. To avoid damage to the heat gun valve & propane cylinder threads, do not overtighten.

**Propane cylinder not included*



OPERATING HEAT GUN:

1. Point burner away from body & any flammable or combustible objects.
2. Turn the ignition/temperature knob counter clockwise approximately 1/4 turn to open valve.
3. Press & release the ignition knob to ignite.
4. You can adjust the temperature setting by turning temperature knob clockwise (-) to decrease heat setting or counter clockwise (+) to increase heat setting.

Note that full power should be achieved by turning knob 1/2 turn in the open position.

5. After use, ensure that the ignition/temperature knob is turned to the off position (turned fully clockwise). Be sure to let nozzle attachments cool before removing. Removing while hot can lead to serious injury.

Do not use any nozzles or attachments that are not supplied for this tool.

Use of other nozzles could result in fire & overheating.

1-YEAR LIMITED WARRANTY

Star Asia-USA, LLC (hereinafter "seller") warrants to the original purchaser only, that this product will be free from defects in material or workmanship for a period of one year from date of purchase.

Warranty Performance

Warranty coverage is conditioned upon purchaser furnishing seller or its authorized service center with adequate written proof of the original purchase date. Products returned, freight prepaid and insured, to our factory or to an Authorized Service Center will be inspected and repaired or replaced, at seller's option, free of charge if found to be defective and subject to warranty. Defective parts not subject to normal wear and tear will be repaired or replaced, at our option during the above stated warranty periods. In any event, reimbursement is limited to the purchase price paid. Other than the postage and insurance requirement, no charge will be made for repairs or replacements covered by this warranty. Under no circumstances shall the manufacturer bear any responsibility for loss of the unit, loss of time or rental, inconvenience, commercial loss or consequential damages. There are no warranties which extend beyond the description of the face hereof.

Exclusions

This warranty does not cover parts damaged due to normal wear, abnormal conditions, misapplication, misuse, abuse, accidents, operation at other than recommended pressures or temperatures, improper storage or freight damage. Parts damaged or worn by operation in dusty environments are not warranted. Failure to follow recommended operating and maintenance procedures also voids warranty. Additional items not covered under this warranty: product failure caused by rain, excessive humidity, corrosive environments or other contaminants; cosmetic defects that do not interfere with product's functionality. This warranty shall not apply when: the product has been used for commercial or rental purposes; defects in materials or workmanship or damages result from repairs or alterations which have been made or attempted by others or the unauthorized use of nonconforming parts; this damage is due to abuse, improper maintenance, neglect or accident; or the damage is due to use of the product after partial failure or use with improper accessories. Seller will not be liable for: labor charges, loss or damage resulting from improper operation, maintenance or repairs made by persons other than a Star Asia-USA, LLC Authorized Service Center. The use of other than genuine Star Asia-USA, LLC Repair Parts will void warranty.

Warranty Disclaimers

NO WARRANTY, ORAL OR WRITTEN, OTHER THAN THE ABOVE WARRANTY IS MADE WITH REGARD TO THIS PRODUCT, ANY IMPLIED WARRANTIES OF SELLER REGARDING THIS PRODUCT INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXCLUDED. BUYER'S OR USER'S REMEDIES ARE SOLELY AND EXCLUSIVELY AS STATED ABOVE. STAR ASIA-USA, LLC SHALL IN NO EVENT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, OR SPECIAL DAMAGES. IN NO EVENT, WHETHER AS A RESULT OF A BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING NEGLIGENCE) OR OTHERWISE, SHALL SELLER'S LIABILITY EXCEED THE PRICE OF THE PRODUCT WHICH HAS GIVEN RISE TO THE CLAIM OR LIABILITY. ANY LIABILITY CONNECTED WITH THE USE OF THIS PRODUCT SHALL TERMINATE UPON THE EXPIRATION OF THE WARRANTY PERIODS SPECIFIED ABOVE.

Limitations on Warranty Disclaimers

Any implied warranties shall be limited in duration to one year from the date of purchase. In some states of the U.S.A. and in some provinces of Canada there is no limitation for how long an implied warranty is valid, so the aforementioned limitation may not apply to you.

In no event shall seller be liable for any incidental or consequential damages (including but not limited to liability for loss of profits) arising from the sale or use of this product. In some states of the U.S.A. and in some provinces of Canada the exclusion or limitation of incidental or consequential damages is not allowed, so the aforementioned limitation or exclusion may not apply to you.

This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state in the U.S.A., Canada and the Commonwealth of Puerto Rico. For warranty coverage within other countries, contact your local Star Asia-USA, LLC dealer or importer.

Distributed by Star Asia-USA, LLC
P.O. Box 58399, Renton, WA 98058
Consumer Service: 800-386-0191
e-mail: info@titan-us.com
©2016 Star Asia-USA, LLC