

Water in your Spill Bucket?

Avoid costly pump-outs by removing water

Spill Bucket Sock

Socks before & after saturation



Spill Bucket Sock Features:

- Quickly & Economically removes water
- Will not absorb fuel
- Swells on contact with water
- Absorbs .8 gallons/sock
- Reduces phase separation & costly pump outs
- Prevents rescheduling of fuel deliveries
- Speeds fuel deliveries
- Hang to dry & re-use




Water overflow causes cap release & leakage into tank



Place sock into water for approximately 5 minutes.



Remove saturated sock & replace if necessary



Socks quickly removed water

ABSORBENT
SPECIALTY PRODUCTS, LLC

Tel: 888-761-4405 Website: www.absorbsp.com
51 Abbott St. Suite # 2, Cumberland, RI 02864
401-722-1177 • Fax 401-722-1160