

iron ton™

SKU: 6688539



1/6 HP 700 CFM AIR MOVER



4 Air Flow Positions



Powerful Air Flow



Rubber Feet for Stability



Stack 5 High For Easy Storage



Carry Handle



Grounded Safety Plug



Wrap Around 10 ft. Cord



3 Wind Speeds

Thank you very much for choosing an Ironton product!
Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This product is designed for certain applications only. Northern Tool and Equipment is not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

For technical questions, please call 1-800-222-5381.

Safety Instructions

WARNING: READ AND SAVE THESE INSTRUCTIONS BEFORE USING THIS PRODUCT.

Users of electrical products may create hazards including injury, fire, or electrical shock. Failure to follow these instructions may damage and/or impair its operation and void the warranty.

- Before operating, remove all packaging material and check for any missing items or damage that may have occurred during shipping.
- Check power supply to ensure it matches the appliance's specification.
- DO NOT** operate any fan with a damaged cord or plug. Discard fan or return it to an authorized service facility for examination and/or repair.
- Use only with GFCI protected receptacles. Please contact a qualified electrician for verification and/or installation of a GFCI receptacle if necessary.
- DO NOT** run cord under carpeting, furniture, or appliances. **Do NOT** cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic areas to avoid tripping.
- To reduce the risk of fire or electric shock, **DO NOT** use this fan with any solid-state speed control device.
- DO NOT** touch this appliance or the plug with wet hands or while standing in water.
- DO NOT** operate the appliance in any pooled water.
- DO NOT** use the product in areas where gasoline, paint or other flammable goods and objects are used or stored.
- DO NOT** insert or allow objects to enter any ventilation or exhaust opening, as this may damage the appliance and void the warranty.
- DO NOT** cover the air inlet or outlet on the appliance.
- DO NOT** direct the air flow at human faces or bodies.
- DO NOT** allow children to play with this appliance.
- AUTOMATICALLY OPERATED DEVICE** - To reduce the risk of injury, disconnect from power supply before servicing.
- Remove the power cord from the electrical receptacle by grasping and pulling on the power cord plug-end only. **DO NOT** pull the cord directly.


- DO NOT** attempt to repair or adjust any electrical or mechanical functions of this appliance as this may cause danger and void the warranty.
- If the appliance is damaged, or it malfunctions, **DO NOT** continue to use it. Unplug the product from the electrical outlet. Refer to trouble shooting guide or contact Northern Tool & Equipment Company, Inc.
- When not in use, store in a dry area, away from sunlight exposure, extreme temperature and humidity, or other extreme environments.

Product Specifications

Voltage/Frequency: 115-120V; 60Hz
Amperage: 1.50 A
Motor Power: 1/6 HP
Max Rated Airflow: 700 CFM
Speed Control: 3 speed settings
Additional Electrical Receptacle: 2 Normal Outlets
Cord Length: 10 ft
Safety Certification: ETLus
Unit Dimension: 12.13 x 11.30 x 13.31 Inch
Unit Weight: Net-8.6 lbs / Gross-10.34 lbs


Operation Guide

Control Panel



- Turn to "OFF" position to switch the air mover OFF. Turn to any speed position to switch the air mover ON.
- Turn clockwise to set the desired speed. 1-Low speed setting; 2-Med speed setting; 3-High speed setting.

Additional Electrical Receptacles (Daisy Chain)




- Other appliances can be plugged into the additional electrical receptacles and will operate whether the Air Mover is on or off. However, the total amperage must be lower than the instructed amperage. Different models may have varying instructions.
- If the Air Mover or the plugged-in appliance stops working, press the “Circuit Reset Button” to reset the circuit.



Multiple Operating Positions & Drying Arrangements


The air mover can operate at various positions, directing the airflow to desired areas.





Single Unit:

Place the air mover at the corner to create circular airflow.



Multiple Units:

Multiple air movers should be spaced about 15 feet apart around the perimeter of room and angled about 15° towards the wall in order to create circular airflow.

Transportation


Stack up to five units (max qty) for convenient and compact storage.



Stack Multiple Units

- Stack the air movers on the sides. Align the air inlets of both air movers.

Organize the Power Cord



- Wrap the power cord around the **curved handle** for storage after use.
- Use convenient clip at end of cord to secure in place.

User Maintenance Instructions

Proper maintenance is recommended on this appliance. Failure to follow the maintenance instructions may cause failure of the appliance and void the warranty.

- When not in use, unplug and store the appliance in a dry and cool indoor place. Make sure it is out of reach for children.
- Before performing any maintenance or cleaning, always disconnect the air mover from its power source.
- Use damp cloth to wipe the surface of the housing. Do not clean the unit with water directly.
- Check if the grille covers are clean. Remove dirt or any other objects that could block the air inlet or air outlet.

Troubleshooting Guide

PROBLEM	POSSIBLE CAUSE	SOLUTION
Air mover does not start	No electricity.	Check for power supply.
	The power cord is not properly plugged in.	Remove and reconnect the power cord.
	The machine is working under an extreme temperature.	Turn off the machine and unplug it. Let the machine cool down to normal temperature.
	The circuit breaker on the additional electrical receptacle (Daisy chain) jumps.	Remove all appliances on the additional electrical receptacle and press "Reset".
Unit runs but the speed is abnormal	Air inlet or air outlet is blocked.	Remove blockage.
The additional electrical receptacle has no power	The circuit breaker on the additional electrical receptacle (Daisy chain) trips.	Remove all appliances on the additional electrical receptacle and press circuit reset button.
	A ground fault causes power interrupt by GFCI.	Turn off and unplug the Air mover. Remove all appliances on the additional electrical receptacle and press GFCI reset button.
The Test Button doesn't react to GFCI test based on the manual	A ground fault causes power interrupt by GFCI.	

Warranty Policy

Northern Tool and Equipment Company, Inc. ("We" or "Us") warrants to the original purchaser only ("You" or "Your") that the Ironton product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of **one year** from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product or product component without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

Obligations of Purchaser

You must retain Your product purchase receipt to verify date of purchase and that You are the original purchaser. To make a warranty claim, contact Us at 1-800-222-5381, identify the product by make and model number, and follow the claim instructions that will be provided. The product and the purchase receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs or costs related to Your return visit to a retail store.

Remedy Limits

Product replacement or a refund of the purchase price is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for: service or labor charges or damage to Your property incurred in removing or replacing the product; any damages, including, without limitation, damages to tangible personal property or personal injury, related to Your improper use, installation, or maintenance of the product or product component; or any indirect, incidental or consequential damages of any kind for any reason.

Assumption of Risk

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

Governing Law

This limited warranty gives You specific legal rights, and You also may have other rights which vary from state to state. Some states do not allow limitations or exclusions on implied warranties or incidental or consequential damages, so the above limitations may not apply to You. This limited warranty is governed by the laws of the State of Minnesota, without regard to rules pertaining to conflicts of law. The state courts located in Dakota County, Minnesota shall have exclusive jurisdiction for any disputes relating to this warranty.

Distributed by:

Northern Tool & Equipment Company, Inc.

Burnsville, Minnesota 55306

www.northerntool.com

Made in VIETNAM