

# ironton™

## ROLLING GARDEN WORK SEAT

Owner's Manual



**! WARNING:** Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Item# 6743753

**READ & SAVE THESE INSTRUCTIONS**

Thank you very much for choosing an Ironton product!

For future reference, please complete the owner's record below:

Serial Number/Lot Date Code (if applicable): \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Save the receipt, warranty, and this manual. It is important that you read the entire manual to become familiar with this product before you begin using it.

This product is designed for certain applications only. Northern Tool and Equipment is not responsible for issues arising from modification or improper use of this product such as an application for which it was not designed. We strongly recommend that this product not be modified and/or used for any application other than that for which it was designed.

For technical questions, please call **1-800-222-5381**.

## Table of Contents

|                                    |           |
|------------------------------------|-----------|
| Intended Use.....                  | 4         |
| Packaging Contents.....            | 4         |
| Technical Specifications .....     | 4         |
| Important Safety Information ..... | 4         |
| Specific Operation Warnings .....  | 7         |
| Grounding .....                    | 错误!未定义书签。 |
| Extension Cords.....               | 错误!未定义书签。 |
| Main Parts of Product .....        | 7         |
| Assembly Instructions.....         | 7         |
| Before Each Use.....               | 9         |
| Operating Instructions.....        | 9         |
| After Each Use.....                | 错误!未定义书签。 |
| Maintenance .....                  | 10        |
| Troubleshooting.....               | 11        |
| Parts Diagram.....                 | 12        |
| Parts List.....                    | 12        |
| Replacement Parts .....            | 13        |
| Limited Warranty .....             | 14        |

## Intended Use

The Rolling Garden Work Seat helps avoid back pain and injury by relieving the pressure caused by continuous stooping, kneeling and squatting. This garden work seat has an old-fashioned tractor seat that swivels in any direction and 10in. pneumatic tires that move over any surface. It comes with a storage area under the seat for your tools, gloves, etc. The seat adjusts up to 18in. off the ground. The heavy-duty, welded steel tube frame has a 330 lb. capacity.

- Weight Capacity:330lb
- 10in. Pneumatic tires
- The seat adjusts up to 18in. off the ground

## Packaging Contents

- Steering link connector (2)
- Steel Seat (1)
- Frame (1)
- Handle support
- Basket (1)
- Poly tray (1)
- Wheel (4)
- Axle (1)
- Small Reinforcing Plate (1)
- Hardware kits (1 bag)

## Technical Specifications

| Property     | Specification                                      |
|--------------|----------------------------------------------------|
| Max Capacity | 330lbs.                                            |
| Tires        | Easy rolling 10" pneumatic tires for rough terrain |
| Construction | Steel                                              |

## Important Safety Information

### **⚠WARNING**

- Read and understand all instructions. Failure to follow all instructions may result in serious injury

or property damage.

- The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that could occur. Exercise common sense and caution when using this tool. Always be aware of the environment and ensure that the tool is used in a safe and responsible manner.
- Do not allow people to operate or assemble the product until they have read this manual and have developed a thorough understanding of how it works.
- Do not modify this product in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the product. There are specific applications for which the product was designed.
- Use the right tool for the job. DO NOT attempt to force small equipment to do the work of larger industrial equipment. There are certain applications for which this equipment was designed. This product will be safer and do a better job at the capacity for which it was intended. DO NOT use this equipment for a purpose for which it was not intended.
- Industrial or commercial applications must follow OSHA requirements.

### **⚠WARNING**

#### **PROP 65**

- This product can expose you to chemicals including lead, which is known to the State of California to cause cancer. For more information, go to [www.p65warnings.ca.gov](http://www.p65warnings.ca.gov).
- Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm. Some examples of these chemicals are:
  - - lead from lead-based paints,
  - - crystalline silica from bricks and cement and other masonry products, and
  - - arsenic and chromium from chemically treated lumber.
- Your risk from these exposures varies depending on how often you do this type of work. To reduce your exposure to these chemicals, work in a well-ventilated area, and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.
- Handling power cords on corded products may expose you to lead, a chemical known to the state of California to cause cancer and birth defects or other reproductive harm. Wash your hands after handling.

### **⚠WARNING**

#### **WORK AREA SAFETY**

- Inspect the work area before each use. Keep work area clean, dry, free of clutter, and well-lit. Cluttered, wet, or dark work areas can result in injury. Using the product in confined work areas may put you dangerously close to cutting tools and rotating parts.
- Do not use the product where there is a risk of causing a fire or an explosion, e.g., in the presence of flammable liquids, gases, or dust. The product can create sparks, which may ignite flammable liquids, gases, or dust.
- Do not allow the product to encounter an electrical source. The tool is not insulated, and contact

will cause electrical shock.

- Keep children and bystanders away from the work area while operating the tool. Do not allow children to handle the product.
- Be aware of all power lines, electrical circuits, water pipes, and other mechanical hazards in your work area. Some of these hazards may be hidden from your view and may cause personal injury and/or property damage if contacted.

## **⚠️WARNING**

### **PERSONAL SAFETY**

- Stay alert, watch what you are doing, and use common sense when operating the tool. Do not use the tool while you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating the tool may result in serious personal injury.
- Dress properly. Do not wear loose clothing, dangling objects, or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts. Air vents on the tool often cover moving parts and should be avoided.
- Wear the proper personal protective equipment when necessary. Use ANSI Z87.1 compliant safety goggles (not safety glasses) with side shields, or when needed, a face shield. Use a dust mask in dusty work conditions. Also use non-skid safety shoes, hard-hat, gloves, dust collection systems, and hearing protection when appropriate. This applies to all people in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Remove keys or wrenches before connecting the tool to an air supply, power supply, or turning on the tool. A wrench or key that is left attached to a rotating part of the tool may cause personal injury.
- Secure the work with clamps or a vise instead of your hand when practical. This safety precaution allows for proper tool operation using both hands.

## **⚠️CAUTION**

### **PRODUCT USE AND CARE**

- Do not force the product. Products are safer and do a better job when used in the manner for which they are designed. Plan your work and use the correct product for the job.
- Check for damaged parts before each use. Carefully check that the product will operate properly and perform its intended function. Replace damaged or worn parts immediately. Never operate the product with a damaged part.
- Do not use a product with a malfunctioning switch. Any power tool that cannot be controlled with the power switch is dangerous and must be repaired by an authorized service representative before using.
- Disconnect the power/air supply from the product and place the switch in the locked or off position before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- Store the product when it is not in use. Store it in a dry, secure place out of the reach of children.

Inspect the tool for good working conditions prior to storage and before re-use.

- Use only accessories that are recommended by the manufacturer for use with your product. Accessories that may be suitable for one product may create a risk of injury when used with another tool. Never use an accessory that has a lower operating speed or operating pressure than the tool itself.
- Keep guards in place and in working order. Never operate the product without the guards in place.
- Do not leave the tool running unattended.

## Specific Operation Warnings

### WARNING



**WARNING:** Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury



**CAUTION:** Do not allow people to operate or assemble this Seat until they have read this manual and have developed a thorough understanding of how it works.



**WARNING:** The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

## Main Parts of Product

| Subassembly |                   |          |        |                    |          |
|-------------|-------------------|----------|--------|--------------------|----------|
| Parts#      | Description       | Quantity | Parts# | Description        | Quantity |
| 01          | Seat              | 1        | 14     | Flat washer 8mm    | 6        |
| 02          | Elevating bolts   | 1        | 15     | Lock Nut M8        | 6        |
| 03          | Main frame        | 1        | 16     | Round Bolt M8x20   | 2        |
| 04          | Basket            | 1        | 17     | Flat Washer 6mm    | 4        |
| 05          | 3.50-4 wheel      | 4        | 18     | Lock Nut M6        | 4        |
| 06          | Connecting Plate  | 1        | 19     | Connecting Plate   | 1        |
| 07          | Axle              | 1        | 20     | Hexagon Bolt M8x25 | 1        |
| 08          | Handle            | 1        | 21     | Cotter Pin         | 1        |
| 09          | Plastic Tray      | 1        | 22     | Wheel Pin          | 4        |
| 10          | Cross Bolt M10x15 | 4        | 23     | Flat Washer 12MM   | 4        |
| 11          | Flat washer M10   | 4        |        |                    |          |

| Subassembly |                  |   |  |  |  |
|-------------|------------------|---|--|--|--|
| 12          | Lock Nut M10     | 4 |  |  |  |
| 13          | Round Bolt M8x20 | 6 |  |  |  |


## Assembly Instructions

### ⚠WARNING


**Read and understand all instructions.** Failure to follow all instructions listed.

Below may result in serious injury.



#### STEP 1




#### STEP 2




#### STEP 3




#### STEP4



#### STEP5



#### STEP6





## Before Each Use

### **⚠WARNING**

- Do not modify the Seat in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the Seat was designed.
- Always check for damaged or worn out parts before using the Seat. Broken parts will affect the Seat's operation. Replace or repair damaged or worn parts immediately.
- Do not exceed the load capacity of the Seat.
- Distribute the load evenly. Uneven loads may cause the Work Seat to tip, resulting in personal injury to the operator or others.
- Use the Seat on flat and level surfaces capable of supporting the maximum load capacity.
- Store the Seat in a secure place out of the reach of children when not in use. Make sure the Seat is in good working condition prior to storage and before each re-use.
- Never stand on Seat.
- Make sure the tires are inflated to 30 PSI, the pressure indicated on the tire sidewall. Do not over inflate: Use a hand pump only. A high-pressure air hose can easily overfill the tires resulting in an explosion and possible injury.

## Operating Instructions

### **⚠WARNING**

- Keep the work area clean, free of clutter and well lit. Cluttered and dark work areas can cause accidents
- Keep children and bystanders away while operating the Seat. Distractions can cause you to lose control, so visitors should remain at a safe distance from the work area. The Seat is not a toy and should not be used as such by children
- Be aware of all power lines, electrical circuits, water pipes and other mechanical hazards in your work area, particularly those hazards below the work surface hidden from the operator's view that may be unintentionally contacted and may cause personal harm or property damage.

1. The Rolling Garden Seat has a full complement of storage options. with a wire basket , poly tray, can storage and holder some gloves, small tools and so on.



- 2 You can sit on the cart, and to do some trimming, weeding, or harvesting .



## Maintenance

### ⚠ WARNING

Maintain your Seat. It is recommended that the general condition of the Seat be examined before it is used. Keep your Work Seat in good working order by adopting a program of conscientious repair and maintenance. If any abnormal vibrations or noise occur, have the problem corrected before further use. Have all necessary repairs made by a qualified service professional.

Maintain the product by adopting a program of conscientious repair and maintenance in accordance with the following recommended procedures. It is recommended that the general condition of any tool be examined before it is used. Keep your tool in good repair. Keep all cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control. Keep handles dry, clean, and free from oil and grease. Also refer to the engine manufacturer's instruction manual for additional information about engine maintenance. The following chart is based on a normal operation schedule.

VENDOR: Here is an example of a maintenance chart. Follow the format given. Replace the information in the table (example below) with the correct information. Add any additional information as needed.

| Maintenance Interval                             | Maintenance Point                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Daily before operating                           | <ol style="list-style-type: none"> <li>1. Use a rag to wipe the body frame, removing dust, dirt and other stains to prevent rusting.</li> <li>2. Check if the wheels are loose and ensure that they rotate smoothly.</li> <li>3. Check if the tire pressure of the vehicle is normal.</li> </ol>                              |
| After the first 20 operating hours               | <ol style="list-style-type: none"> <li>1. Clean the wheel bearings and apply the special lubricant to ensure smooth wheel rotation.</li> </ol>                                                                                                                                                                                |
| After the first 50 operating hours or every week | <ol style="list-style-type: none"> <li>1. Check all the screws and nuts, and tighten them as necessary to prevent the components from loosening and falling off.</li> <li>2. Inspect the metal parts of the frame, check for any signs of rust. If there are any, perform rust removal and apply a rust inhibitor.</li> </ol> |

## Troubleshooting

### ⚠ WARNING


- VENDOR: Provide embedded warnings as needed.

VENDOR: Describe any problems that may occur with the product and how to fix the problems. Use the table below as an example on how to fill in the table. Replace the information on the table (example below) with the information. Add any additional information as needed.

Use the table below to solve problems before contacting service personnel or your local dealer. If the problem continues after troubleshooting, call your local dealer for assistance.

| Failure                           | Possible Cause                                                           | Corrective Action                                              |
|-----------------------------------|--------------------------------------------------------------------------|----------------------------------------------------------------|
| Storage basket loose and deformed | Placing items that are too heavy                                         | Avoid placing overly heavy items in the storage basket.        |
|                                   | The connection between the storage basket and the vehicle body is loose. | Regularly inspect the connecting parts and tighten the screws. |
| Poor steering responsiveness      | Lack of lubrication                                                      | Apply lubricating grease to the steering components            |
|                                   | Installation error                                                       | Reinstall and re-adjust                                        |
|                                   | Wear of the steering components                                          | Replace the steering components in time                        |
| Wheel misalignment                | inner tube break or flat                                                 | replace the inner tube or inflate the tyre                     |
|                                   | Incorrect wheel installation                                             | Adjust the installation angle of the wheels                    |
|                                   | Unequal tire pressure                                                    | Uniform tire pressure                                          |
|                                   |                                                                          |                                                                |
|                                   |                                                                          |                                                                |

## Parts Diagram



## Parts List

| Reference | Part Number | Part Description  | Quantity |
|-----------|-------------|-------------------|----------|
| 1         | 01#         | Seat              | 1        |
| 2         | 02#         | Elevating bolts   | 1        |
| 3         | 03#         | Main frame        | 1        |
| 4         | 04#         | Basket            | 1        |
| 5         | 05#         | 3.50-4 wheel      | 4        |
| 6         | 06#         | Connecting Plate  | 1        |
| 7         | 07#         | Axle              | 1        |
| 8         | 08#         | Handle            | 1        |
| 9         | 09#         | Plastic Tray      | 1        |
| 10        | 10#         | Cross Bolt M10x15 | 4        |
| 11        | 11#         | Flat washer M10   | 4        |
| 12        | 12#         | Lock Nut M10      | 4        |
| 13        | 13#         | Round Bolt M8x20  | 6        |

| Reference | Part Number | Part Description   | Quantity |
|-----------|-------------|--------------------|----------|
| 14        | 14#         | Flat washer 8mm    | 6        |
| 15        | 15#         | Lock Nut M8        | 6        |
| 16        | 16#         | Round Bolt M8x20   | 2        |
| 17        | 17#         | Flat Washer 6mm    | 4        |
| 18        | 18#         | Lock Nut M6        | 4        |
| 19        | 19#         | Connecting Plate   | 1        |
| 20        | 20#         | Hexagon Bolt M8x25 | 1        |
| 21        | 21#         | Cotter Pin         | 1        |
| 22        | 22#         | Wheel Pin          | 1        |
| 23        | 23#         | Flat Washer 12MM   | 4        |

## Replacement Parts

- For replacement parts and technical questions, please call Customer Service at **1-800-222-5381**.
- Not all product components are available for replacement. The illustrations provided are a convenient reference to the location and position of parts in the assembly sequence.
- When ordering parts, the following information will be required: item description, item model number, item serial number/item lot date code, and the replacement part reference number.
- The distributor reserves the right to make design changes and improvements to product lines and manuals without notice.

## Limited Warranty

Northern Tool and Equipment Company, Inc. ("We" or "Us") warrants to the original purchaser only ("You" or "Your") that the Ironton product purchased will be free from material defects in both materials and workmanship, normal wear and tear excepted, for a period of **one year** from date of purchase. The foregoing warranty is valid only if the installation and use of the product is strictly in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. If the product does not comply with this limited warranty, Your sole and exclusive remedy is that We will, at our sole option and within a commercially reasonable time, either replace the product or product component without charge to You or refund the purchase price (less shipping). This limited warranty is not transferable.

### Limitations on the Warranty

This limited warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

### Obligations of Purchaser

You must retain Your product purchase receipt to verify date of purchase and that You are the original purchaser. To make a warranty claim, contact Us at 1-800-222-5381, identify the product by make and model number, and follow the claim instructions that will be provided. The product and the purchase receipt must be provided to Us in order to process Your warranty claim. Any returned product that is replaced or refunded by Us becomes our property. You will be responsible for return shipping costs or costs related to Your return visit to a retail store.

### Remedy Limits

Product replacement or a refund of the purchase price is Your sole remedy under this limited warranty or any other warranty related to the product. We shall not be liable for: service or labor charges or damage to Your property incurred in removing or replacing the product; any damages, including, without limitation, damages to tangible personal property or personal injury, related to Your improper use, installation, or maintenance of the product or product component; or any indirect, incidental or consequential damages of any kind for any reason.

### Assumption of Risk

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

### Governing Law

This limited warranty gives You specific legal rights, and You also may have other rights which vary from state to state. Some states do not allow limitations or exclusions on implied warranties or incidental or consequential damages, so the above limitations may not apply to You. This limited warranty is governed by the laws of the State of Minnesota, without regard to rules pertaining to conflicts of law. The state courts located in Dakota County, Minnesota, shall have exclusive jurisdiction for any disputes relating to this warranty.

# iron<sup>+</sup>ton™

Distributed by:

Northern Tool & Equipment Company, Inc.

Burnsville, Minnesota 55306

[www.northerntool.com](http://www.northerntool.com)

Made in Vietnam