

# XP1812

## PRO Triangle LED Worklight



### Features

- Rugged design
- Swivel area light
- Protective rubberized armor
- Collapsible hook
- Magnetic base
- Auto shutoff when closed
- 2 Modes: High / Low
- Weather resistant IPX4

### Operation Instructions

- On/Off:** Press button and release or swivel the head into the closed position.
- Cycle Modes:** Press and release button (High/Low)

### Usage and Maintenance

**Battery Replacement:** In a dry environment, locate the battery access door opposite from the on/off button. Press lightly and push the battery access door down. Remove batteries. Insert new batteries into the tubes following the +/- symbols to ensure proper battery arrangement. Carefully reinstall the battery access door by pushing lightly upwards until the door clicks into the closed position.

**Care Instructions:** If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.



ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	1050 lm	7h	60 m
Low	440 lm	35h	30m

### Product Warranty

Limited 90-Day Warranty against manufacturer's defects from time of purchase. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to [info@simpleproducts.com](mailto:info@simpleproducts.com).