NPower Flex-Powerpack – 24928

Instructions for installing a U1-Type Battery

In order to put the battery in this Powerpack, first open up the back of the pack, and then remove the black battery expansion chamber anchored by 2 small screws. Once this chamber is removed, the U1 fits snugly and securely in the back. This black expansion chamber is included with the Powerpack to make it that more versatile by accommodating much smaller sized batteries.