




# **TEAR-DOWN TABLE WITH DRAIN**

## **OWNER'S MANUAL**



 **WARNING:** Read carefully and understand all **INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

**Item #380012**

Thank you very much for choosing a NORTHERN TOOL + EQUIPMENT CO., INC. Product! For future reference, please complete the owner's record below:

Model: \_\_\_\_\_ Purchase Date: \_\_\_\_\_

Save the receipt, warranty and these instructions. It is important that you read the entire manual to become familiar with this product before you begin using it.

This machine is designed for certain applications only. The distributor cannot be responsible for issues arising from modification. We strongly recommend this machine is not modified and/or used for any application other than that for which it was designed. If you have any questions relative to a particular application, DO NOT use the machine until you have first contacted the distributor to determine if it can or should be performed on the product.

For technical questions please call **1-800-222-5381**.

## INTENDED USE

Super heavy-duty table is ready for projects like engine rebuilding. Features a drain with pan to catch engine oil.

## TECHNICAL SPECIFICATIONS

Item	Description
Load capacity	1000 lbs.
Overall dimension	47 1/5in. x 31 1/2in. x 41in.
Wheel type	Locking casters

## GENERAL SAFETY RULES



**WARNING: Read and understand all instructions.** Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.



**WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur.** It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

## SAVE THESE INSTRUCTIONS

- Always keep work area clean. Cluttered areas invite injuries. Keep children away from work area. Never allow children on or near work area.
- Always observe work area conditions. Never use equipment in damp, wet locations or expose them to rain. Always keep work area well lit. Never use electrically powered tools in the presence of flammable gases or liquids.
- Guard against electric shock. Prevent body contact with grounded surfaces such as pipes, radiators, ranges and refrigerator enclosures.

- Do not smoke, strike a match, or cause a spark around the equipment.
- Always use this equipment in a well ventilated area.



**WARNING!** DO NOT allow discharged fluids to the pollute the environment.

## TOOL USE AND CARE

- Store idle equipment when not in use. Tools must be stored in a dry location to prevent rust. Always keep tools locked up and away from children.
- Always use the correct tool for job needed. There are certain application for which this tool was designed. It will do the job better and more safety at the rate for which it was intended. Do not modify this tool and never use this tool for a purpose for which it was not intended.
- Never overreach. Keep proper footing and balance at all times. Never reach over or across running machines.
- Use eye and ear protection. Other people in work area must also wear ANSI approved impact safety goggles.
- Stay alert. Always use common sense and watch what you are doing. Never operate any tool when you are tired.
- Place this equipment on a flat, level, hard surface. Always lock the swivel casters with locks to prevent unintentional rolling of the table.
- Never operate tool under the influence of drugs or alcohol. Read warning labels when taking prescription medicine to determine if your judgment or reflexes might be impaired due to use. If there is any doubt, do not operate tool.
- Avoid solvent contact with skin and eyes. Do not touch your eyes after working with the equipment. Use gloves. Use ANSI approved safety goggles for eye protection. If solvent contacts skin, face, or eyes, immediately flush with plenty of fresh water. Then contact a doctor.
- Do not exceed rated capacity of this product: 1000-lb load capacity
- Dispose all hazardous waste, following local government regulation. Do not dispose waste in a sewer, stream or ocean.

## ASSEMBLY

The Tear-Down Table is shipped in three cartons. Carton 1 of 3 contains the top table panel. Carton 2 of 3 contains legs, casters and plastic drain receptacle. Carton 3 of 3 contains the metal drawer. After unpacking, check to make sure all parts shown on the Parts Diagram are included.

**When assembling, more than one person is needed for stabilizing parts being assembled and for lifting table.**


1. Use Screws (Part #3), Washers (Part #5), and Nuts (Part #4) to bolt the legs to top of the Table (Part #6). Put top of the Table face down on the floor in this step; be sure to protect the finish of top of the Table.
2. Secure the Panels (Part #11) with Screws, Washers and Nuts to the predrilled holes.
3. Use Screws, Washers, and Nuts to attach the Frame for the Drawer (Part #7) to under the top of Table using the predrilled holes closer to the front of the top of Table.
4. Pull Metal Drawer (Part #8B) out of the Metal Drawer Housing (Part #8A) and use Screws to

- attach the Metal Drawer Housing to the Frame for the Drawer.
5. Slide the Metal Drawer into track by lifting up the rear of the drawer.
  6. Install the Lock (Part #13) at the back of the drawer. Push the button on each side into the predrilled holes to keep drawer from sliding out too far.
  7. Slide the Plastic Tub (Part #9) in the tracks under the top Table. Screw in the two M8x30 Screws (Part #12) into the holes on the track. This will keep Plastic Tub from sliding out too far. Remove the M8x30 Screws to empty fluid in the Plastic Tub.
  8. Use Screws, Washers and Nuts to attach two Swivel Casters (Part #1) to the Legs (Part #2) on one side of the table, following the Parts Diagram.
  9. Use Screws, Washers and Nuts to attach two Swivel Casters with Locks (Part #10) to the Legs on the other side of the table, following the Parts Diagram.

## **MAINTENANCE**

- Maintain tools with care. Always keep tools clean for better and safer performance. Never operate tool if any portions of the tools operating controls are inoperable, disconnected, altered or not working properly.
- Check for any damaged parts. Always inspect every tool for damages prior to using it. If part looks damaged careful inspection should be made to determine if it will operate or perform its intended function. Any part that is damaged should be properly repaired or replaced by qualified technician.
- Replacement parts and accessories. This product is to be repaired and serviced only by a qualified technician. Only identical replacement parts should be used when this product is serviced. The use of any other parts will void the warranty. Only use accessories intended for use with this tool.
- Maintenance. The maintenance outlined in the maintenance section should be performed regularly. For your safety this product should only be serviced or repaired by a qualified technician.
- Use non-corrosive, water-based cleaning solvents only. Do not use any flammable solvents, such as gasoline, toluene, or diesel fuel. Do not use any solvents which create hazardous fumes.
- Use non-skid footwear or safety shoes. Keep proper footing and balance at all times.
- When not in use, have it drained, cleaned, and then stored in a dry location to reduce rust.

# DIAGRAM & PARTS LIST



Part#	Description	Qty.	Part#	Description	Qty.
01	Swivel caster	2	08A	Metal drawer housing	1
02	Leg	2	08B	Metal drawer	1
03	Screw (M8X15)	48	09	Plastic tub	1
04	Nut (M8)	44	10	Swivel caster with lock	2
05	Washer	44	11	Panel	2
06	Top of table	1	12	Screw (M8X30)	2
07	Frame for the drawer	1	13	Lock and keys set	1

For replacement parts and technical questions, please call **1-800-222-5381**.

# WARRANTY

One-Year Limited Warranty



Distributed by  
Northern Tool + Equipment Co., Inc.  
Burnsville, MN 55306  
Made in China