

The fan required to be assembled after your getting from package carton.

1. Install the wall bracket (No. 10) on the strong wall by it screw base set (No.11)
2. Install the motor (No. 9) on the support wall bracket (No.10)
3. Assembling Rear Guard (No.7) to the motor (No.9) with the motor screw set (No. 6)
4. Insert fan blade (No.5) into the Motor Shaft (No.8) and lock it with its screw (No.4)
5. Hold the front guard (No.3) at right position with Company's logo upright, fit with rear guard then secure it by its guard ring (No. 2) and its screw (No.1)
6. Switchbox can be mounted on wall by its accessories

OPERATION & MAINTENANCE

Place the fan on a safe place, flat surface where it cannot fall or be pulled by the cord

1. Plug unit into electrical outlet
2. Select preferred speed (1-Low, 2-Medium, 3-High) by rotating the switch knob or pressing the button on the control box.
 - TO ADJUST UPWARD OR DOWNWARD, use hand to adjust it carefully
 - TO MAKE THE FAN OSCILLATE, use hand to pull up and STOP oscillation by push down.

Always turn off and unplug fan after using.

Maintain your fan. It is recommended that the general condition of any fan be examined before it is used. Keep your fan in good repair and maintenance in accordance with manufacturer instruction.

- a. Check regularly and schedule inspection are recommended
- b. Check for unusual noises
- c. Periodically inspect and tighten all bolts, screws...
- d. Use a soft, damp cloth (water only) for cleaning, then wipe with dry cloth.
- e. Do not use cleaners that harm paints or plastics; i.e., bleach or ammonia.
- f. Do not bend blades.

Northern Tool and Equipment Company, Inc.

2800 Southcross Drive, W., Burnsville, Minnesota 55306

NorthernTool.com



INSTRUCTION MANUAL

OSCILLATING WALL MOUNTED FAN

KWP SERIES (20in)

Models: #4742837 (KWP-2050)



! WARNING: Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

READ & SAVE THIS INSTRUCTION MANUAL

TECHNICAL SPECIFICATIONS

Model.	Size	Voltage	Power	CFM	RPM
4742837 KWP-2050	20in	120V/60Hz	164W	3600	1225

IMPORTANT SAFETY INFORMATION

! WARNINGS

- Read carefully and understand all Assembly and Operation instruction before using. Failure to follow the safety rules and precautions may result in serious injury
- The warnings, cautions and instructions in this manual cannot cover all possible conditions or situations that could occur. Always be aware of the environment and ensure that the fan is used in a safe and responsible manner
- Do not assemble and operate the product before completely reading all the manual and understand how it works
- Only use with rated voltage
- If the power cord is damaged, it must be replaced by technician or qualified person to avoid any hazard
- Do not modify this product in anyway. Unauthorized modification may impair the function and/or safety and could affect the life of the product.
- To avoid the possibility of causing injury to user or damage properties, please follow the instructions in this manual. The manufacturer is not responsible for accidents and injuries caused by wrong installation.
- The product was designed for right application, DO NOT attempt to use it for a purpose for which it was not intended.
- Do not use the product where is a risk of causing a fire or explosion in the presence of flammable liquids, gases or similar.
- This fan is not intended for use by children or people with reduced physical, sensory or mental capabilities or lack of experience and knowledge unless they have been give supervision or instruction concerning use of the fan by a person responsible for their safety.
- Children should be supervised to ensure they are not allowed to play with the fan.
- Suitable for commercial or industrial use only

! CAUTIONS

- Check for damaged parts before use, carefully check that the fan will operate properly and perform its intended function. Replace damaged part immediately. Never operate the fan with a damaged part.
- Do not use a fan with a malfunctioning switch, any fan that can not be controlled with the power switch is dangerous and must be replaced or repaired by an authorized service provider before using.
- Automatically Operated Device – To Reduce The Risk Of Injury Disconnect From Power Supply Before Servicing.

- Do not operate the fan with a damaged cord or Plug. Discard or Return the fan to the authorized service center for examination and/or repair.
- Discounted the power from the fan and place the switch in the locked or off position before making any adjustments. Such preventive safety measures reduce the risk of starting the fan accidentally
- Store the fan at dry and secure place when its not in use.
- Electric shock Hazard. Do not expose the fan to rain or water
- Keep it out of the reach of children
- Do not leave the fan running unattended.
- For indoor use only. Do not use outdoors. Do not place the fan in or near a window. Rain may create an electrical hazard.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for repair before resuming operation.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings.
- Do not place cord under furniture or appliances. Arrange cord away from a higher traffic area and where it will not be tripped over.

ASSEMBLY

